

T.O. 31W1-2FCC-103

20 APR 1976

TECHNICAL MANUAL
CIRCUIT DIAGRAMS

**MULTIPLEXER SET AN/FCC-17,
AN/FCC-21, AN/FCC-22,
AND ASSOCIATED EQUIPMENT**

AF30(635)-33973
F34601-67-C-4452

THIS PUBLICATION REPLACES T.O. 31W1-2FCC-103 DATED 22 MAY 1964

PUBLISHED UNDER AUTHORITY OF THE SECRETARY OF THE AIR FORCE

Reproduction for non-military use of the information or illustrations contained in this publication is not permitted without specific approval of the issuing service. The policy for use of Classified Publications is established for the Air Force in AFR 205-1.

Technical orders are normally distributed promptly after printing. Date(s) shown on the title page (lower right) are for identification only. This is not a distribution date. Processing time sometimes causes distribution to only appear to have been delayed.

LIST OF EFFECTIVE PAGES

INSERT LATEST CHANGED PAGES. DESTROY SUPERSEDED PAGES.

NOTE: The portion of the text affected by the changes is indicated by the vertical line in the outer margins of the page. Changes to illustrations are indicated by miniature pointing hands. Changes to wiring diagrams are indicated by shaded areas.

Dates of issue for original and changed pages are:
Original..0..15 May 69

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 98 CONSISTING OF THE FOLLOWING:

<i>Page No.</i>	<i>Change No.</i>
Title	0
A	0
i-iii	0
iv Blank	0
v-vii	0
viii Blank	0
ix-xiii	0
xiv Blank	0
1-82	0

Upon receipt of the second and subsequent changes to this technical order, personnel responsible for maintaining this publication in current status will ascertain that all previous changes have been received and incorporated. Action should be taken promptly if the publication is incomplete.

*The asterisk indicates pages changed, added, or deleted by the current change.

ADDITIONAL COPIES OF THIS PUBLICATION MAY BE OBTAINED BY USAF ACTIVITIES
IN ACCORDANCE WITH T.O. 00-5-2.

USAF

TABLE OF CONTENTS


<u>Figure</u>		<u>Page</u>
	INTRODUCTION	v
	BLOCK DIAGRAMS	
1	Transmission Equipment (Sheet 1 of 2)	1
1	Transmission Equipment (Sheet 2 of 2)	2
2	Carrier Supply Equipment (Sheet 1 of 3)	3
2	Carrier Supply Equipment (Sheet 2 of 3)	4
2	Carrier Supply Equipment (Sheet 3 of 3)	5
	TRANSMISSION EQUIPMENT SCHEMATICS	
3	Channel Multiplexer Shelf	6
4	Channel Demultiplexer Shelf	7
5	Group Pilot Alarm Shelf	8
6	Group Multiplexer Shelf	9
7	Group Demultiplexer Shelf	10
8	Low-Level Supergroup Modulator Tray (Supergroups 1 through 10)	11
9	High-Level Supergroup Modulator Tray (Supergroups 1 and 1A)	12
10	Supergroup Demodulator Tray	13
11	Supergroup Modulator Combining Panel	14
12	Supergroup Modulator Combining Panel (72-Channel)	15
13	Line Connector Panel	16
14	Supergroup Demodulator Combining Panel	17
15	Supergroup Demodulator Combining Panel (72-Channel)	18
	CARRIER SUPPLY EQUIPMENT SCHEMATICS	
16	Master Frequency Generator Shelf (Sheet 1 of 2)	19
16	Master Frequency Generator Shelf (Sheet 2 of 2)	20
17	Channel Carrier Supply Shelf (Sheet 1 of 2)	21
17	Channel Carrier Supply Shelf (Sheet 2 of 2)	22
18	Channel Carrier Amplifier Shelf (Sheet 1 of 2)	23
18	Channel Carrier Amplifier Shelf (Sheet 2 of 2)	24
19	Group Carrier Generator Shelf (Sheet 1 of 2)	25
19	Group Carrier Generator Shelf (Sheet 2 of 2)	26
20	Group Carrier Supply Shelf (Sheet 1 of 2)	27
20	Group Carrier Supply Shelf (Sheet 2 of 2)	28

TABLE OF CONTENTS (Cont)

<u>Figure</u>		<u>Page</u>
CARRIER SUPPLY EQUIPMENT SCHEMATICS (Cont)		
21	Group Carrier Amplifier Shelf (Sheet 1 of 2)	29
21	Group Carrier Amplifier Shelf (Sheet 2 of 2)	30
22	Supergroup Carrier Generator Shelf	31
23	Supergroup Carrier Supply Shelf (Sheet 1 of 3)	32
23	Supergroup Carrier Supply Shelf (Sheet 2 of 3)	33
23	Supergroup Carrier Supply Shelf (Sheet 3 of 3)	34
24	Supergroup Carrier Amplifier Shelf (Sheet 1 of 2)	35
24	Supergroup Carrier Amplifier Shelf (Sheet 2 of 2)	36
POWER AND ALARM EQUIPMENT SCHEMATICS		
25	Power Supply Shelf	37
26	Fuse Panels (Sheet 1 of 2)	38
26	Fuse Panels (Sheet 2 of 2)	39
27	Master Alarm Panel	40
MISCELLANEOUS EQUIPMENT SCHEMATICS		
28	Handset and Handset Patch Panel	41
CABLING DIAGRAMS		
29	Multiplexer Set AN/FCC-21 (Sheet 1 of 7)	42
29	Multiplexer Set AN/FCC-21 (Sheet 2 of 7)	43
29	Multiplexer Set AN/FCC-21 (Sheet 3 of 7)	44
29	Multiplexer Set AN/FCC-21 (Sheet 4 of 7)	45
29	Multiplexer Set AN/FCC-21 (Sheet 5 of 7)	46
29	Multiplexer Set AN/FCC-21 (Sheet 6 of 7)	47
29	Multiplexer Set AN/FCC-21 (Sheet 7 of 7)	48
30	Multiplexer Set AN/FCC-22 (Sheet 1 of 15)	49
30	Multiplexer Set AN/FCC-22 (Sheet 2 of 15)	50
30	Multiplexer Set AN/FCC-22 (Sheet 3 of 15)	51
30	Multiplexer Set AN/FCC-22 (Sheet 4 of 15)	52
30	Multiplexer Set AN/FCC-22 (Sheet 5 of 15)	53
30	Multiplexer Set AN/FCC-22 (Sheet 6 of 15)	54
30	Multiplexer Set AN/FCC-22 (Sheet 7 of 15)	55
30	Multiplexer Set AN/FCC-22 (Sheet 8 of 15)	56
30	Multiplexer Set AN/FCC-22 (Sheet 9 of 15)	57
30	Multiplexer Set AN/FCC-22 (Sheet 10 of 15)	58
30	Multiplexer Set AN/FCC-22 (Sheet 11 of 15)	59
30	Multiplexer Set AN/FCC-22 (Sheet 12 of 15)	60
30	Multiplexer Set AN/FCC-22 (Sheet 13 of 15)	61
30	Multiplexer Set AN/FCC-22 (Sheet 14 of 15)	62

TABLE OF CONTENTS (Cont)

<u>Figure</u>		<u>Page</u>
CABLING DIAGRAMS (Cont)		
30	Multiplexer Set AN/FCC-22 (Sheet 15 of 15)	63
31	Multiplexer Set AN/FCC-17 (Sheet 1 of 19)	64
31	Multiplexer Set AN/FCC-17 (Sheet 2 of 19)	65
31	Multiplexer Set AN/FCC-17 (Sheet 3 of 19)	66
31	Multiplexer Set AN/FCC-17 (Sheet 4 of 19)	67
31	Multiplexer Set AN/FCC-17 (Sheet 5 of 19)	68
31	Multiplexer Set AN/FCC-17 (Sheet 6 of 19)	69
31	Multiplexer Set AN/FCC-17 (Sheet 7 of 19)	70
31	Multiplexer Set AN/FCC-17 (Sheet 8 of 19)	71
31	Multiplexer Set AN/FCC-17 (Sheet 9 of 19)	72
31	Multiplexer Set AN/FCC-17 (Sheet 10 of 19)	73
31	Multiplexer Set AN/FCC-17 (Sheet 11 of 19)	74
31	Multiplexer Set AN/FCC-17 (Sheet 12 of 19)	75
31	Multiplexer Set AN/FCC-17 (Sheet 13 of 19)	76
31	Multiplexer Set AN/FCC-17 (Sheet 14 of 19)	77
31	Multiplexer Set AN/FCC-17 (Sheet 15 of 19)	78
31	Multiplexer Set AN/FCC-17 (Sheet 16 of 19)	79
31	Multiplexer Set AN/FCC-17 (Sheet 17 of 19)	80
31	Multiplexer Set AN/FCC-17 (Sheet 18 of 19)	81
31	Multiplexer Set AN/FCC-17 (Sheet 19 of 19)	82



INTRODUCTION

PURPOSE. This manual provides circuit diagrams necessary to support installation and maintenance of Multiplexer Sets AN/FCC-21, -22, and -17, and associated equipment.

SCOPE. The manual includes the following diagrams: block diagrams of the transmission equipment and carrier supply equipment; schematic diagrams of major components; cabling diagrams for the three multiplexer sets.

Circuits of reparable modules are usually shown in simplified form by a combination of graphical and block symbols. For the complete schematic diagram, refer to the technical publication for the module, which is listed in Chapter 1 of the Service manual, T.O. 31W1-2FCC-102.

ARRANGEMENT. The schematic diagrams of major components are divided into equipment groups and arranged in signal flow sequence in each group. In the transmission equipment schematics, the diagram of each major component in the transmitting branch is followed by its counterpart in the receiving branch.

Jackfields and terminal board panels do not have separate schematic diagrams, but circuits through them are included in the cabling diagrams.

A separate cabling diagram is provided for each of the three multiplexer sets. Each diagram shows complete details of wiring within the rack and identifies external and inter-rack connections.

ALTERED-CIRCUIT DIAGRAMS. When applicable, changes in basic circuitry between different models or serial numbers of the equipment will be shown by altered-circuit diagrams. An altered-circuit diagram will have the same figure number and title as the basic diagram. The page number will be the same as the basic diagram followed by a decimal point and an Arabic numeral. The numerals will identify different variations of the same basic diagram; for example: 12.1, 12.2, and 12.3.

ABBREVIATIONS. Because of their frequent use in this and associated manuals, the following abbreviations are defined below:

BE	Band elimination
DEM	Demodulator
DMX	Demultiplexer
COND	Conductor
EQ	Equalizer
EQUIP.	Equipment
FIL	Filter
GR	Group
GRD	Ground
JK	Jackfield
MFG	Master frequency generator
MX	Multiplexer

NET.	Network
SGR	Supergroup
SUP.	Supply
PAR	Parallel
XMFR	Transformer

GRAPHIC SYMBOLS. Electrical and electronic symbols are in accordance with MIL-STD-15-1A. A pin jack, telephone jack, or coaxial jack used as a test point is emphasized by a 3/16-inch diameter solid circle.

DEFINITIONS OF EQUIPMENT TERMS.

Components of the multiplexer set are classified by size, method of mounting, and type of electrical interface according to the terms defined below. These terms appear in many of the common names of components; on diagrams, they may be omitted from the name where space is limited.

a. Rack. This term may refer to the rack as a mounting frame, but when used with modifiers, it means the rack and its complement of equipment (channel equipment rack, for example).

b. Shelf. A shelf is a rack-mounted drawer of equipment that can be extended outward on a slide-rail mechanism without interrupting its operation. The height of the shelf is a multiple of 1-3/4 inches (standard rack mounting space); weights are in the range of 15 to 90 pounds. Intra-rack wiring enters through one or more electrical receptacles at the rear of the shelf.

c. Panel. A panel is an immobile rack-mounted chassis; panel heights are in multiples of 1-3/4 inches. Intra-rack wiring is soldered to terminals on the electrical components of the panel.

d. Jackfield. A jackfield is a rack-mounted chassis, similar to a panel, on

which groups of telephone jacks or coaxial jacks are mounted. The jacks provide access to the transmitting and receiving circuits of the multiplexer set.

e. Tray. The multiplexer set has two types of trays. One type (power supply tray and master frequency generator tray) is the major subassembly of a shelf; two identical trays are mounted side-by-side and plug into the shelf. The second type (supergroup modulator tray and supergroup demodulator tray) is similar to the first in size but uses a different electrical interface. Two of these supergroup trays are mounted on an equipment support, which has slide rails like a shelf but no electrical circuitry; intra-rack wiring enters through electrical receptacles at the rear of the tray.

f. Module. A module is an enclosed (usually hermetically-sealed) electrical subassembly of a shelf, panel, or tray. Most modules have 7-pin or 9-pin headers, which plug into mating sockets on the chassis; others (usually filters and networks) have header terminals to which soldered connections are made.

LEVELS. A level in dbm means actual power. A level in db means a reading on a meter calibrated in dbm referenced to 600 ohms.

On a meter calibrated to read dbm in a 600-ohm circuit, the level in dbm for other circuit impedances can be determined by algebraically adding to the meter reading as follows:

75 ohms: add +9 db

135 ohms: add +6.5 db

150 ohms: add +6 db

In the transmission path, signal levels specified are for a single-channel test tone. Group pilot levels and 96-kc sync pilot level are -16 dbm0 (16 db below test tone level).

PART NUMBERS. For equipment having optional configurations, a suffix "-xx" is used in the part number to indicate that more than one dash number is applicable.

STRAPPING. Optional strapping, which is indicated on the schematic diagrams by the letter S in a triangular symbol, is described in Chapter 2 of the Service manual.

GENERAL NOTES. The following are general notes for the circuit diagrams in this manual.

a. Reference designations. Reference designations are abbreviated. Prefix with assembly designation to form the complete reference designation.

b. Component values. Unless otherwise specified, values are in ohms and microfarads.

c. Dc resistance. The dc resistance of a coil or transformer winding is shown if


it is one ohm or more. However, resistance is not shown if the coil or winding is inside a sealed module.

d. Waveforms. Waveforms on the schematic diagrams are typical for normal operation but are not intended to be used as performance standards.

e. Alarm circuit power. Alarm circuit power leads are designated as 40V and COM. The voltage between these leads may be 40 vac or 48 vdc, depending on whether the master alarm panel obtains power from an external 120-volt ac source or from a 48-volt office battery. (The 400-cps master alarm panel produces 40-volt dc alarm circuit power.)

f. Relays. Relays are shown in normal operating position.

g. Terminal symbol. Where necessary to maintain signal flow on schematic diagrams, a terminal symbol may be repeated. At its second appearance, the symbol is broken.



CROSS REFERENCE INDEX

NOTE: For asterisked (*) items, schematic diagram lists additional part numbers or nomenclature.

COMMON NAME AND MFR PART NO.	NOMENCLATURE	PAGE
Channel carrier amplifier shelf 790-01261-01	Amplifier-Control Group OA-6119/MCC-13	23
Channel carrier supply shelf 790-01150-01	Telephone Carrier Frequency Supply Group OA-4126/GCC	21
Channel demultiplexer shelf 790-01149-01	Demultiplexer Group OA-4104/GCC	7
Channel multiplexer shelf 790-01148-01	Multiplexer Group OA-4103/GCC	6
Fuse panel, 790-03307-01	Fuse Panel SB-1298/FCC-17	38
Fuse panel, 790-03349-01	Fuse Panel SB-1296/FCC-17	38
Fuse panel, 790-03358-01	Fuse Panel SB-1276/FCC-17	38
Fuse panel, 790-03360-01	Fuse Panel SB-1297/FCC-17	38
Fuse panel, 790-03362-01	Fuse Panel SB-1294/FCC-17	38
Fuse panel, 790-03364-01	Fuse Panel SB-1295/FCC-17	38
Fuse panel, 790-11501-01	Fuse Panel SB-2932/FCC	39
Fuse panel, 790-11502-01	Fuse Panel SB-2922/FCC	39
Fuse panel, 790-11571-01	Fuse Panel SB-2924/FCC	39
Fuse panel, 790-11574-01	Fuse Panel SB-2921/FCC	39
Fuse panel, 790-12601-01	Fuse Panel SB-2931/FCC	39

CROSS REFERENCE INDEX (Cont)

COMMON NAME AND MFR PART NO.	NOMENCLATURE	PAGE
Fuse panel, 790-12604-01	Fuse Panel SB-3078/UCC-4(V)	39
Group carrier amplifier shelf 790-04072-01	Radio Frequency Amplifier Group AM-3157/FCC-17 (Same as OG-49/UCC-4(V))	29
Group carrier generator shelf 790-02152-01	Telephone Carrier Frequency Supply Group OA-4110/GCC	25
Group carrier supply shelf 790-02199-01	Telephone Carrier Frequency Supply Group OA-4113/GCC	27
*Group demultiplexer shelf 790-01640-01	Demultiplexer Group OA-4105/GCC	10
Group jackfield 790-03885-01	Telephone Jack Assembly TA-417/FCC-17	65
Group jackfield 790-07832-01	Telephone Jack Assembly TA-574/FCC	42, 43
Group jackfield 790-11503-01	Telephone Jack Assembly SB-2934/FCC	49
*Group multiplexer shelf 790-02062-01	Multiplexer Group OA-4114/GCC	9
*Group pilot alarm shelf 790-01351-01	Control-Monitor Group OA-4106/MCC-12	8
Handset 747-00418-01	Handset H-222/MCC-12	41
Handset patch panel 790-03354-01	Communication Patching Panel TA-420/MCC-12	41
Handset patch panel 790-11714-01	Communication Patching Panel SB-3080/UCM-1	41
*Line connector panel 790-03029-01	Impedance Matching Network CU-936/MCC-12	16
Master alarm panel, 60-cps 790-02506-01	Indicator-Power Supply ID-1077/MRC-98	40

CROSS-REFERENCE INDEX (Cont)


COMMON NAME AND MFR PART NO	NOMENCLATURE	PAGE
Master alarm panel, 400-cps 790-03319-01	Control-Indicator C-3668/MCC-12	40
*Master frequency generator shelf 790-05155-01	Telephone Carrier Frequency Supply Group OA-4127/MCC-12	19
*Master frequency generator shelf 790-05685-01	Telephone Carrier Frequency Supply TA-495/MRC-98	19
*Master frequency generator tray 790-05112-01	Telephone Carrier Frequency Supply Group OA-4128/MCC-12	19
*Master frequency generator tray 790-05683-01	Telephone Carrier Frequency Supply Group OA-6791/FCC	19
*Power supply shelf 790-01855-01	Power Supply Set OA-6830/FCC	37
Power supply shelf 790-02963-01	Power Supply Set OA-4109/MCC-12	37
*Power supply shelf 790-07975-01	Power Supply Assembly OA-6445/FCC	37
Power supply tray 790-01866-01	Power Supply PP-4115/FCC	37
Power supply tray 790-02964-01	Power Supply PP-3498/MCC-12	37
Power supply tray 790-07974-01	Power Supply PP-3965/FCC	37
Supergroup carrier amplifier shelf, 790-04971-01	Amplifier-Relay Group OA-7320/UCC-4(V)	35
Supergroup carrier generator shelf, 790-02881-01	Telephone Carrier Frequency Supply Group TA-418/FCC-17 (Same as OA-8368/UCC-4(V))	31
Supergroup carrier supply shelf 790-02880-01	Radio Frequency Amplifier Group AM-2995/FCC-17 (Same as OG-48/UCC-4(V))	32


CROSS-REFERENCE INDEX (Cont)

COMMON NAME AND MFR PART NO.	NOMENCLATURE	PAGE
*Supergroup demodulator combining panel, 790-03533-01	Combining Network MX-3569/FCC-17	17
*Supergroup demodulator combining panel (72-channel), 790-07211-01	Frequency Divider CU-1273/MCC-13	18
*Supergroup 1A demodulator tray 790-03273-01	Telephone Carrier Demodulator Group OA-4111/MCC-12	13
*Supergroup 1 demodulator tray 790-03931-01	Signal Data Translator Group OM-5/FCC-64	13
Supergroup 1 demodulator tray 790-07226-01	Telephone Carrier Demodulator Group OA-6122/MCC-13	13
*Supergroup 2 demodulator tray 790-03932-01	Amplifier-Filter AM-3182/FCC-17	13
Supergroup 2 demodulator tray 790-07227-01	Amplifier-Attenuator Group OA-6123/MCC-13	13
*Supergroup demodulator tray (sgr 3 through 10), 790-03933-01 through 790-03940-01	Signal Data Translator MD-439 through MD-446/FCC-17	13
Supergroup jackfield 790-02878-01, -02	Telephone Jack Assembly J-1276/FCC-17	64,66
Supergroup jackfield 790-11573-01	Telephone Jack Assembly SB-2933/FCC	50
*Supergroup modulator combining panel, 790-03532-01	Combining Network MX-3570/FCC-17	14
*Supergroup modulator combining panel (72-channel), 790-07210-01	Radio Frequency Combiner CU-1274/MCC-13	15
Supergroup 1A modulator tray 790-03077-01	Telephone Carrier Modulator Group OA-4112/MCC-12	12
*Supergroup 1A modulator tray 790-06980-02	Telephone Carrier Modulator Group OA-6442/FCC	12

CROSS-REFERENCE INDEX (Cont)


COMMON NAME AND MFR PART NO.	NOMENCLATURE	PAGE
Supergroup 1 modulator tray (low-level), 790-03901-01	Signal Data Translator MD-428/FCC-17	11
*Supergroup 1 modulator tray (high-level), 790-07259-02	Telephone Carrier Modulator Group OM-8/FCC-17	12
Supergroup 2 modulator tray 790-03902-01	Band Pass Filter F-642/FCC-17	11
Supergroup 2 modulator tray 790-06999-01	Telephone Attenuator-Filter CN-1157/FCC-60	11
Supergroup modulator tray (sgr 3 thru 10), 790-03903-01 thru 790-03910-01	Signal Data Translator MD-429 thru MD-436/FCC-17 (Same as OM-18 thru OM-25/UCC-4(V))	11





- NOTES
- [101] STRAPPING REQUIRED FOR SLAVE TERMINAL OPERATION.
 - [102] POWER READINGS INDICATED ARE BRIDGING TYPE MADE WITH A 500 OHM AC VTVM FLAT METER CORRECTED TO DBM.
 - [103] POWER READINGS SHOWN ARE OF A NOMINAL VALUE AND MAY VARY ± 2 DB FROM THE INDICATED POWER.
 - [104] READINGS SHOWN IN FRACTION FORM INDICATE POWER CORRECTED TO DBM IN THE NUMERATOR AND CIRCUIT IMPEDANCE IN THE DENOMINATOR POSITION.
 - [105] THE A ALARM CONTROLS ARE CONTAINED IN THE SAME MODULE.
 - [106] THE B ALARM CONTROLS ARE CONTAINED IN THE SAME MODULE.
 - [107] TEST POINTS ARE ISOLATED TO READ 0.23V (-16DB) ON 500 OHM AC VTVM BRIDGING, 0 DB ON TRANSMISSION TEST SET.)
 - [108] STRAP AS REQUIRED FOR CHANNEL LOADING.
 - [109] DASHED LINE PAD SYMBOL INDICATES ASSOCIATED LEVEL CHANGE RESULTING FROM INPUT PAD STRAPPING.
 - [110] DIRECT CURRENT TEST POINT. USE 20,000 OHMS PER VOLT VOM.

Figure 2. Carrier Supply Equipment, Block Diagram (Sheet 1 of 3)




- NOTES
- 201. ALL POWER READINGS INDICATED ARE BRIDGING TYPE MADE ON AN OPERATING UNIT WITH A 600 OHM AC VTVM FLAT METER CORRECTED TO DBM.
 - 202. POWER READINGS SHOWN ARE OF A NOMINAL VALUE AND MAY VARY ±2 DB FROM THE INDICATED POWER.
 - 203. READINGS SHOWN IN FRACTION FORM INDICATE POWER CORRECTED TO DBM IN THE NUMERATOR AND CIRCUIT IMPEDANCE IN THE DENOMINATOR POSITION.
 - 204. THE A ALARM CONTROLS IN EACH SHELF ARE CONTAINED IN THE SAME MODULE.
 - 205. THE B ALARM CONTROLS IN EACH SHELF ARE CONTAINED IN THE SAME MODULE.
 - 206. TRANSMISSION TEST SET METERING POINTS ARE ISOLATED TO READ +12.5V, -16 DB ON 600 OHM ACVTVM BRIDGING, 0 DB ON TRANSMISSION TEST SET.
 - 207. STRAP AS NECESSARY FOR GROUP MODULATOR LOADING REQUIREMENTS.
 - 208. STRAP AS REQUIRED TO PROVIDE EITHER 564 KC OR 612 KC SUPERGROUP 1 CARRIER FREQUENCY.
 - 209. LEVELS INDICATED ARE FOR EACH FREQUENCY WHEN MEASURED WITH A FREQUENCY SELECTIVE METER.

TO GROUP MULTIPLEXERS GROUP DEMULTIPLEXERS +6 DBM 150 OHMS ONE GR LOAD MIN +16 DBM 15 OHMS 10 GR LOAD MAX

TO SGR CARRIER AMPLIFIER -6.5 DBM 75 OHM LOAD

TO SGR MOD AND DEM +11 DBM 75 OHMS, ONE SGR LOAD MIN +14 DBM 37.5 OHMS, TWO SGR


Figure 2. Carrier Supply Equipment, Block Diagram (Sheet 2 of 3)



- NOTES
- 301. POWER READINGS INDICATED ARE BRIDGING TYPE MADE WITH A 600 OHM ACVTVM FLAT METER CORRECTED TO DBM.
 - 302. POWER READINGS SHOWN ARE OF A NOMINAL VALUE AND MAY VARY ± 2 DB FROM THE INDICATED POWER.
 - 303. STRAP AS REQUIRED TO MATCH MODULATOR LOADING.
 - 304. ALARM CIRCUIT FOR UNEQUIPPED AMPLIFIER POSITIONS MUST BE BYPASSED BY STRAPPING.
 - 305. STRAPPING REQUIRED TO PROVIDE EITHER SEPARATE OR COMBINED INPUT.
 - 306. TEST POINTS ARE ISOLATED TO READ 0.123 VOLT (-6 DB) ON 600 OHM BRIDGING AC VTVM, 0DB ON TRANS TEST SET.
 - 307. CARRIER FREQUENCY INPUT LEVEL FOR SUPERGROUP 1 IS -6.5 DBM AND REQUIRES 36 DB AMPLIFIERS, CARRIER FREQUENCY INPUT LEVEL FOR SUPERGROUPS 3 THRU 10 IS -1.5 DBM AND REQUIRES 33 DB AMPLIFIERS.

6 SEPARATE OUTPUTS TO SUPERGROUP MODULATORS AND/OR DEMODULATORS +10.5 DBM 75 OHMS, 1 MODULATOR OR ONE DEMODULATOR, +13.5 DBM 37.5 OHMS, 2 MOD OR 2 DEM OR 1 MOD AND 1 DEM


Figure 2. Carrier Supply Equipment, Block Diagram (Sheet 3 of 3)



19-16603

OPTIONAL STRAPPING. REFER TO CHAPTER 2 OF SERVICE MANUAL.

Figure 3








TABLE A

CHANNEL MULTIPLEXER SHELF	
PART NO.	790-01148-01
NOMENCLATURE	MULTIPLEXER GROUP 0A-4103/GCC





OPTIONAL STRAPPING. REFER TO CHAPTER 2 OF SERVICE MANUAL.

Figure 3. Channel Multiplexer Shelf, Schematic Diagram

TABLE A

GROUP PILOT ALARM SHELF		GROUPS EQUIPPED OO									
PART NO.	NOMENCLATURE, CONTROL-MONITOR GROUP	1/L	2/L	3/L	4/L	5/L	1/R	2/R	3/R	4/R	5/R
-01	OA-4106/MCC-12	X	X	X	X	X					
-02	OK-16/FCC	X	X	X	X	X	X	X	X	X	X
-03		X	X	X	X	X					
-04	OA-4599/MRC-98			X	X	X					
-05				X	X	X					
-06	OA-6448/FCC-30	X	X	X	X	X					
-07		X	X	X	X	X					
-08	OA-7036/FCC-28	X									
-09	OA-7502/FCC					X					
-10		X	X	X	X	X					
-11		X	X	X	X	X					
-12	OA-6451/FCC-27	X	X	X	X	X	X	X	X	X	X
-13		X	X	X	X	X	X	X	X	X	X
-14		X	X	X	X	X	X	X	X	X	X
-15		X	X	X	X	X	X	X	X	X	X
-16		X	X	X	X	X	X	X	X	X	X
-17		X	X	X	X	X	X	X	X	X	X
-18		X	X	X	X	X	X	X	X	X	X
-19											
-20											
-21		X	X	X	X	X	X	X	X	X	X
-22		X	X	X	X	X	X	X	X	X	X
-23		X	X	X	X	X	X	X	X	X	X
-24		X	X	X	X	X	X	X	X	X	X
-25		X	X				X	X	X	X	X
-26		X	X				X	X	X	X	X
-27		X	X				X	X	X	X	X
-28		X	X	X	X	X	X	X	X	X	X
-29		X	X	X	X	X	X	X	X	X	X
-30		X	X	X	X	X	X	X	X	X	X
-31		X	X	X	X	X	X	X	X	X	X
-32		X	X	X	X	X	X	X	X	X	X
-33		X	X	X	X	X	X	X	X	X	X
-34		X	X	X	X	X	X	X	X	X	X
-35		X	X	X	X	X	X	X	X	X	X
-36		X	X	X	X	X	X	X	X	X	X
-37		X	X	X	X	X	X	X	X	X	X
-38		X	X	X	X	X	X	X	X	X	X
-39		X	X	X	X	X	X	X	X	X	X
-40							X	X			X
-41							X	X			X
-42				X	X		X	X			X
-43				X	X	X	X	X	X	X	X
-44		X					X	X	X	X	X
-45		X					X	X	X	X	X
-46		X	X	X			X	X	X	X	X



- NOTES:
1. IN THE GROUP DESIGNATIONS (GR 1/L AND GR 1/R, FOR EXAMPLE), L AND R DENOTE LEFT SIDE AND RIGHT SIDE OF THE SHELF.
 2. FOR EACH EQUIPPED GROUP (TABLE A), A PLUG-IN ALARM CONTROL MODULE AND ALARM RELAY ARE FURNISHED.




Figure 5. Group Pilot Alarm Shelf, Schematic Diagram




Figure 4. Channel Demultiplexer Shelf, Schematic Diagram





TABLE A

PART NO. 790-01640-	NOMENCLATURE: DEMULTIPLXER GROUP	*EQUIPPED GROUPS (X)				
		1	2	3	4	5
-01	0A-4105/GCC	X	X	X	X	X
-02	0A-4598/MRC-98			X	X	X
-03				X	X	X
-04	0A-6449/FCC-30	X	X	X	X	X
-05		X	X	X	X	X
-06	0B-33/FCC-17	X			X	X
-07	0A-7503/FCC			X	X	X
-08				X	X	X
-09		X	X			
-10	0A-6452/FCC-27	X	X	X	X	
-11		X	X	X	X	
-12		X		X	X	X
-13				X	X	
-14		X		X	X	
-15		X	X	X	X	X
-16		X	X	X	X	X

*FOR EACH EQUIPPED GROUP, A PLUG-IN GROUP DEMODULATOR MODULE IS FURNISHED.



NOTE: CIRCUITS OF BANDPASS FILTERS A6 THRU A10 ARE SHOWN ON THE SCHEMATIC DIAGRAM OF THE GROUP MULTIPLEXER SHELF IN THIS MANUAL.

Figure 7. Group Demultiplexer Shelf, Schematic Diagram





Figure 8. Low-Level Supergroup Modulator Tray (Supergroups 1 through 10), Schematic Diagram




TABLE A

SGR MODULATOR TRAY		ALARM CONTROL A6 AND A7	
SGR	PART NO.	NOMENCLATURE: TELEPHONE CARRIER MODULATOR GROUP	MONITOR PILOT
1A	790-03077-01	0A-4112/MCC-12	790-02344-01 GR 1, 20
1A	790-06980-02	0A-6442/FCC	790-05173-02 GR 4, 64
1A	790-06980-03	0A-4595/MRC-98	790-05173-03 GR 5, 16
1A	790-06980-04	0A-7506/FCC	790-05173-04 GR 2, 16
1A	790-06980-05		790-05173-03 GR 3, 11
1A	790-06980-06		790-07258-01 GR 1, 25
I	790-07259-01		790-05173-02 GR 5, 64
I	790-07259-02	0M-8/FCC-17	

NOTES:
 1. THE LINE SGR FREQUENCY OF 12-252 KC (SGR 1A) OR 60-300 KC (SGR 1) IS MARKED ADJACENT TO JACKS J5 THRU J8.
 2. SGR MOD TRAY PN 790-03077-01 REQUIRES DC ALARM CIRCUIT POWER (40V, COM). SUBASSEMBLY A10 IS OMITTED AND THE K3 RELAY CONTROL CIRCUIT IS CHANGED TO THE FOLLOWING:




Figure 9. High-Level Modulator Tray (Subassembly A10) Schematic





Figure 8. Low-I for Tr through




TABLE A

SGR MODULATOR TRAY		ALARM CONTROL A6 AND A7	
SGR	PART NO.	NOMENCLATURE: TELEPHONE CARRIER MODULATOR GROUP	MONITORED PILOT
1A	790-03077-01	0A-4112/MCC-12	790-02344-01
1A	790-06980-02	0A-6442/FCC	790-02344-01
1A	790-06980-03	0A-4595/MRC-98	790-05173-02
1A	790-06980-04	0A-7506/FCC	790-05173-01
1A	790-06980-05		790-05173-04
1A	790-06980-06		790-05173-03
1	790-07259-01		790-07258-01
1	790-07259-02	0M-8/FCC-17	790-05173-02

NOTES:
 1. THE LINE SGR FREQUENCY OF 12-252 KC (SGR 1A) OR 60-300 KC (SGR 1) IS MARKED ADJACENT TO JACKS J5 THRU J8.
 2. SGR MOD TRAY PN 790-03077-01 REQUIRES DC ALARM CIRCUIT POWER (40V, COM). SUBASSEMBLY A10 IS OMITTED AND THE K3 RELAY CONTROL CIRCUIT IS CHANGED TO THE FOLLOWING:




Figure 9. High-Level Supergroup Modulator Tray (Supergroups 1 and 1A), Schematic Diagram

C2-L2 ARE NOT USED ON 273-XX, 790-07226-01, ARE NOT USED ON SGR 2 POWER CIRCUITS (-48V V/G PAD) ARE OMITTED. SGR 3, 4, 6, 7, AND 8, GROUND CONNECTION ON 2 AS SHOWN. (THE CONNECTION BETWEEN TERMINALS 1 AND 2 IS NOT MADE ADJACENT TO JACKS J2 AND J3). THE SGR FREQUENCY ARE: SGR 1: 312-552 KC; SGR 2: 312-552 KC; SGR 3: 312-552 KC; SGR 4: 312-552 KC; SGR 5: 312-552 KC; SGR 6: 312-552 KC; SGR 7: 312-552 KC; SGR 8: 312-552 KC; SGR 9: 312-552 KC; SGR 10: 312-552 KC. A9 MONITOR ONE OF THE 312-552 KC SGR FREQUENCY. THE SGR DEM TRAY IN THIS SCHEMATIC DIAGRAM IS IDENTIFIED BY THE NUMBER, REFER TO THE SCHEMATIC DIAGRAM FOR THE PART NUMBERS OF SGR DEM TRAY WHICH ARE APPLICABLE TO A SGR DEM TRAY WHICH HAS BEEN ASSIGNED TO THE SGR DEM TRAY IN THIS SCHEMATIC DIAGRAM.




TABLE A

SGR	SGR DEM TRAY	A1 SGR FILTER	A2 CARRIER FILTER	DEMODULATOR	A8 AND A9 ALARM CONTROL	NOTES
1A	790-03273-XX	300-KC LP 792-05301-01	564-KC BP 792-05382-01	790-02580-01	SEE TABLE B.	1
1	790-03931-XX	300-KC LP 792-05301-01	612-KC BP 792-05381-01	790-02580-01	SEE TABLE C.	2
2	790-03932-XX	312-552 KC BP 792-05302-01	NOT USED	SGR RCVG PAD 790-02603-01		3
3	790-03933-XX	564-804 KC BP 792-05303-01	1116-KC BP 792-05383-01	790-02611-01		3
4	790-03934-XX	812-1052 KC BP 792-05304-01	1364-KC BP 792-05384-01	790-02611-01		3
5	790-03935-XX	1060-1300 KC BP 792-05305-01	1612-KC BP 792-05385-01	790-02611-01		3
6	790-03936-XX	1308-1548 KC BP 792-05306-01	1860-KC BP 792-05386-01	790-02611-01		3
7	790-03937-XX	1556-1796 KC BP 792-05307-01	2108-KC BP 792-05387-01	790-02611-01		3
8	790-03938-XX	1804-2044 KC BP 792-05308-01	2356-KC BP 792-05388-01	790-02611-01		3
9	790-03939-XX	2052-2292 KC BP 792-05309-01	2604-KC BP 792-05389-01	790-02611-01		
10	790-03940-XX	2300-2540 KC BP 792-05310-01	2852-KC BP 792-05390-01	790-02611-01		
1	790-07226-01	300-KC LP 792-05301-01	612-KC BP 792-05381-01	790-02580-01	790-02282-01 (MONITORS 356-KC PILOT IN GR 1)	1
2	790-07227-01	312-552 KC BP 792-05302-01	NOT USED	SGR RCVG PAD 790-02603-01		1, 2

TABLE B

SGR 1A DEM TRAY	A8 AND A9 ALARM CONTROL PART NO.	MONITORED PILOT
790-03273-01	790-02282-01	GR 1, 356 KC
-02	790-05088-02	GR 4, 500 KC
-03	-01	GR 5, 548 KC
-04	-05	GR 2, 404 KC
-05	-06	GR 3, 452 KC

TABLE C

* SGR DEM TRAY DASH NO. (-XX)	A8 AND A9 ALARM CONTROL PART NO.	MONITORED PILOT
-01	790-02282-01	GR 1, 356 KC
-02	790-05088-01	GR 5, 548 KC
-03	-02	GR 4, 500 KC
-04	-06	GR 3, 452 KC
-05	-05	GR 2, 404 KC

* APPLICABLE TO 790-03931-XX THRU 790-03940-XX

Figure 10. Supergroup Demodulator Tray, Schematic Diagram




TABLE A

SGR MODULATOR COMBINING PANEL		SGR MOD EQUIPPED	ANNULLING NETWORK	
PART NO.	NOMENCLATURE		A2	A3
790-03532-				
-01	COMBINING NETWORK MX-3570/FCC-17	1 THRU 10	792-05331-01	792-05332-01
-02	COMBINING NETWORK MX-751.5/FCC	1, 2, OR 1 AND 2	NOT USED	NOT USED
-03		3 AND 4	792-05333-01	792-05334-01
-04		1 THRU 4	792-05335-01	792-05336-01
-05		1 THRU 3	792-05335-01	NOT USED
-06		2 THRU 5	792-05337-01	792-05336-01
-07		1 THRU 5	792-05339-01	792-05336-01
-08		3	792-05333-01	NOT USED
-09	SUMMATION NETWORK CU-1786/FCC-17	2 THRU 6 OR 3 THRU 6	792-05337-01	792-05338-01
-10		1 THRU 6	792-05339-01	792-05338-01

TABLE A (CONT)

SGR MODULATOR COMBINING PANEL		SGR MOD EQUIPPED	ANNULLING NETWORK	
PART NO.	NOMENCLATURE		A2	A3
790-03532-				
-11		1 THRU 4 AND 6	792-05335-01	792-05338-01
-12		3, 4, AND 6	792-05333-01	792-05338-01
-13	SUMMATION NETWORK CU-1787/FCC-17	2 THRU 4	792-05333-01	792-05336-01

TABLE B

ANNULLING NETWORK	FIG.
792-05331-01	C
792-05332-01	D
792-05333-01	E
792-05334-01	E
792-05335-01	F
792-05336-01	D
792-05337-01	G
792-05338-01	C
792-05339-01	C




Figure 11. Supergroup Modulator Combining Panel, Schematic Diagram

NOTES:

- 1 DECOUPLING NETWORKS C1-L1 AND C2-L2 ARE NOT USED ON SGR DEMODULATOR TRAYS 790-03273-XX, 790-07226-01, AND 790-07227-01.
- 2 CARRIER FILTER A2 AND JACK J6 ARE NOT USED ON SGR 2 DEMODULATOR TRAYS. ALSO, DC POWER CIRCUITS (-48V AND GRD) TO MODULE A3 (SGR RCVG PAD) ARE OMITTED.
- 3 ON SGR DEMODULATOR TRAYS FOR SGR 3, 4, 6, 7, AND 8, SGR FILTER A1 HAS A CHASSIS GROUND CONNECTION ON TERMINAL 4 INSTEAD OF TERMINAL 2 AS SHOWN. (THE FILTER HAS AN INTERNAL CONNECTION BETWEEN TERMINALS 2 AND 4.)
- 4 THE APPLICABLE SGR NO. IS MARKED ADJACENT TO JACKS J2 AND J6.
- 5 THE APPLICABLE SGR NO. AND LINE SGR FREQUENCY ARE MARKED ADJACENT TO JACK J3.
- 6 ALARM CONTROL MODULES A8 AND A9 MONITOR ONE OF THE FIVE GROUP PILOTS IN THE 312-552 KC SGR FREQUENCY BAND. WHEN THE PART NO. OF THE SGR DEM TRAY IN TABLE A INCLUDES -XX AS A DASH NUMBER, REFER TO TABLE B (790-03273-XX) OR TABLE C (790-03931-XX THRU 790-03940-XX) TO DETERMINE PART NUMBERS OF SGR DEM TRAY AND ALARM CONTROL MODULE APPLICABLE TO A PARTICULAR GROUP PILOT.
- 7 SGR DEMODULATOR TRAYS THAT HAVE BEEN ASSIGNED NOMENCLATURE ARE LISTED IN TABLE D.
- 8 CIRCUITS OF THE SGR FILTERS (792-05301-01 THRU 792-05310-01) ARE SHOWN ON THE SCHEMATIC DIAGRAM OF THE LOW-LEVEL SGR MODULATOR TRAY IN THIS MANUAL.

TABLE D [7]

PART NO.	NOMENCLATURE
790-03273-01	TELEPHONE CARRIER DEMODULATOR GROUP OA-4111/MCC-12
790-03273-02	TELEPHONE CARRIER DEMODULATOR GROUP OA-4597/MRC-98
790-03273-03	TELEPHONE CARRIER DEMODULATOR GROUP OA-7504/FCC
790-03931-01	SIGNAL DATA TRANSLATOR OM-5/FCC-64
790-03931-02	TELEPHONE CARRIER DEMODULATOR GROUP OM-3/FCC-65
790-03931-03	SIGNAL DATA TRANSLATOR CV-2262/FCC-63
790-03932-01	AMPLIFIER-FILTER AM-3182/FCC-17
790-03933-01	SIGNAL DATA TRANSLATOR MD-439/FCC-17
790-03934-01	SIGNAL DATA TRANSLATOR MD-440/FCC-17
790-03935-01	SIGNAL DATA TRANSLATOR MD-441/FCC-17
790-03936-01	SIGNAL DATA TRANSLATOR MD-442/FCC-17
790-03937-01	SIGNAL DATA TRANSLATOR MD-443/FCC-17
790-03938-01	SIGNAL DATA TRANSLATOR MD-444/FCC-17
790-03939-01	SIGNAL DATA TRANSLATOR MD-445/FCC-17
790-03940-01	SIGNAL DATA TRANSLATOR MD-446/FCC-17
790-07226-01	TELEPHONE CARRIER DEMODULATOR GROUP OA-6122/MCC-13
790-07227-01	AMPLIFIER-ATTENUATOR GROUP OA-6123/MCC-13




TABLE A

SGR	SGR DEM TRAY [6]	A1 SGR FILTER	A2 CARRIER FILTER	A3 DEMODULATOR	A8 AND A9 ALARM CONTROL	NOTES
1A	790-03273-XX	300-KC LP 792-05301-01	564-KC BP 792-05382-01	790-02580-01	SEE TABLE B.	1
1	790-03931-XX	300-KC LP 792-05301-01	612-KC BP 792-05381-01	790-02580-01	SEE TABLE C.	2
2	790-03932-XX	312-552 KC BP 792-05302-01	NOT USED	790-02603-01		2
3	790-03933-XX	564-804 KC BP 792-05303-01	1116-KC BP 792-05383-01	790-02611-01		3
4	790-03934-XX	812-1052 KC BP 792-05304-01	1364-KC BP 792-05384-01	790-02611-01		3
5	790-03935-XX	1060-1300 KC BP 792-05305-01	1612-KC BP 792-05385-01	790-02611-01		3
6	790-03936-XX	1308-1548 KC BP 792-05306-01	1860-KC BP 792-05386-01	790-02611-01		3
7	790-03937-XX	1556-1796 KC BP 792-05307-01	2108-KC BP 792-05387-01	790-02611-01		3
8	790-03938-XX	1804-2044 KC BP 792-05308-01	2356-KC BP 792-05388-01	790-02611-01		3
9	790-03939-XX	2052-2292 KC BP 792-05309-01	2604-KC BP 792-05389-01	790-02611-01		3
10	790-03940-XX	2300-2540 KC BP 792-05310-01	2852-KC BP 792-05390-01	790-02611-01		3
1	790-07226-01	300-KC LP 792-05301-01	612-KC BP 792-05381-01	790-02580-01	790-02282-01 (MONITORS 356-KC PILOT IN GR 1)	1
2	790-07227-01	312-552 KC BP 792-05302-01	NOT USED	790-02603-01	SGR RCVG PAD	1, 2


TABLE B [6]

SGR 1A DEM TRAY	A8 AND A9 ALARM CONTROL PART NO.	MONITORED PILOT
790-03273-01	790-02282-01	GR 1, 356 KC
-02	790-05088-02	GR 4, 500 KC
-03	-01	GR 5, 548 KC
-04	-05	GR 2, 404 KC
-05	-06	GR 3, 452 KC

TABLE C [6]

* SGR DEM TRAY DASH NO. (-XX)	A8 AND A9 ALARM CONTROL PART NO.	MONITORED PILOT
-01	790-02282-01	GR 1, 356 KC
-02	790-05088-01	GR 5, 548 KC
-03	-02	GR 4, 500 KC
-04	-06	GR 3, 452 KC
-05	-05	GR 2, 404 KC

* APPLICABLE TO 790-03931-XX THRU 790-03940-XX






TABLE A

SGR MODULATOR COMBINING PANEL		SGR MOD EQUIPPED	ANNULLING NETWORK	
PART NO. 790-03532-	NOMENCLATURE		A2	A3
-01	COMBINING NETWORK MX-3570/FCC-17	1 THRU 10	792-05331-01	792-05332-01
-02	COMBINING NETWORK MX-7515/FCC	1, 2, OR 1 AND 2	NOT USED	NOT USED
-03		3 AND 4	792-05333-01	792-05334-01
-04		1 THRU 4	792-05335-01	792-05336-01
-05		1 THRU 3	792-05335-01	NOT USED
-06		2 THRU 5	792-05337-01	792-05336-01
-07		1 THRU 5	792-05339-01	792-05336-01
-08		3	792-05333-01	NOT USED
-09	SUMMATION NETWORK CU-1786/FCC-17	2 THRU 6 OR 3 THRU 6	792-05337-01	792-05338-01
-10		1 THRU 6	792-05339-01	792-05338-01

TABLE A (CONT)

SGR MODULATOR COMBINING PANEL		SGR MOD EQUIPPED	ANNULLING NETWORK	
PART NO. 790-03532-	NOMENCLATURE		A2	A3
-11		1 THRU 4 AND 6	792-05335-01	792-05338-01
-12		3, 4, AND 6	792-05333-01	792-05338-01
-13	SUMMATION NETWORK CU-1787/FCC-17	2 THRU 4	792-05333-01	792-05336-01

TABLE B

ANNULLING NETWORK	FIG.
792-05331-01	C
792-05332-01	D
792-05333-01	E
792-05334-01	E
792-05335-01	F
792-05336-01	D
792-05337-01	G
792-05338-01	C
792-05339-01	C





Figure 11. Supergroup Modulator Combining Panel, Schematic Diagram



OPTIONAL STRAPPING. REFER TO CHAPTER 2 OF SERVICE MANUAL.

RESISTANCES IN PARENTHESES ARE APPLICABLE TO 790-07210-02 AND -04.

TABLE B

ATTEN, DB	STRAP A8 TERMINALS			
0	A-K			
1	A-B	C-K		
2	A-D	E-K		
3	A-B	C-D	E-K	
4	A-F		G-K	
5	A-B	C-F	G-K	
6	A-D	E-F	G-K	
7	A-B	C-D	E-F	G-K

TABLE B (CONT)

ATTEN, DB	STRAP A8 TERMINALS				
8	A-H			J-K	
9	A-B	C-H		J-K	
10	A-D	E-H		J-K	
11	A-B	C-D	E-H	J-K	
12	A-F		G-H	J-K	
13	A-B	C-F	G-H	J-K	
14	A-D	E-F	G-H	J-K	
15	A-B	C-D	E-F	G-H	J-K

TABLE A

SGR MODULATOR COMBINING PANEL		INPUT LEVEL, DBM	FREQ RANGE, KC
PART NO. 790-07210-	NOMENCLATURE		
-01	RF COMBINER CU-1274/MCC-13	-36.5	60-552
-02		-19.5	
-03		-36.5	12-552
-04		-19.5	

849-16692

Figure 12. Supergroup Modulator Combining Panel (72-Channel), Schematic Diagram





TABLE A

LINE CONNECTOR PANEL		HF XMTG LEVEL, DBM			HF RCVG LEVEL, DBM			RESISTANCE, OHMS			
PART NO.	NOMENCLATURE	MAX	MIN	+0 DB ON TEST SET	MAX	MIN	+0 DB ON TEST SET	A1R13	A1R14	A1R15	A2R16
-01	IMPEDANCE MATCHING NETWORK CU-936/MCC-12	-20	-23.5	-20	-22.5	-26	-26	3830	3830	75	1780
-02	IMPEDANCE MATCHING NETWORK CU-1154/MRC-98	-20	-23.5	-23	-22.5	-26	-23	3830	2610	75	2610
-03		-37	-40.5	-40	-22.5	-26	-26	31.6K	619	1210	1780

*LEVEL (TEST TONE) FOR WHICH TRANSMISSION TEST SET READS 0 DB AT APPLICABLE TEST JACK, HF OUT OR HF IN.




Figure 13. Line Connector Panel, Schematic Diagram




TABLE B

ATTEN, DB	STRAP A8 TERMINALS
0	A-K
1	A-B C-K
2	A-D E-K
3	A-B C-D E-K
4	A-F G-K
5	A-B C-F G-K
6	A-D E-F G-K
7	A-B C-D E-F G-K

TABLE B (CONT)

ATTEN, DB [A]	STRAP A8 TERMINALS
8 (1 2)	A-H J-K
9 (1 3)	A-B C-H J-K
10 (1 4)	A-D E-H J-K
11 (1 5)	B C-D E-H J-K
12 (1 6)	A-F G-H J-K
13 (1 7)	A-B C-F G-H J-K
14 (1 8)	A-D E-F G-H J-K
15 (1 9)	A-B C-D E-F G-H J-K

TABLE A

SGR DEMODULATOR COMBINING PANEL PART NO. 790-07211-	NOMENCLATURE	*INPUT LEVEL, DBM	FREQ RANGE, KC
-01	FREQUENCY DIVIDER CU-1273/MCC-13	-10	60-552
-02		-15	
-03		-15	12-552

*HF RCVG LEVEL (TEST TONE) AT WHICH TRANSMISSION TEST SET READS 0 DB.

Figure 15. Supergroup Demodulator Combining Panel (72-Channel), Schematic Diagram




TABLE A

SGR DEMODULATOR COMBINING PANEL		ANNULLING NETWORK	
PART NO. 790-03533-	NOMENCLATURE	SGR DEM EQUIPPED	
-01	COMBINING NETWORK MX-3569/FCC-17	1 THRU 10	790-05331-01 790-05332-01
-02	COMBINING NETWORK MX-7516/FCC	1, 2 OR 1 AND 2	NOT USED NOT USED
-03		3 AND 4	790-05333-01 790-05334-01
-04		1 THRU 4	790-05335-01 790-05336-01
-05		1 THRU 3	790-05335-01 NOT USED
-06		2 THRU 5	790-05337-01 790-05336-01
-07		1 THRU 5	790-05339-01 790-05336-01
-08		3	790-05333-01 NOT USED
-09	SUMMATION NETWORK CU-1785/FCC-17	2 THRU 6 OR 3 THRU 6	790-05337-01 790-05338-01
-10		1 THRU 6	790-05339-01 790-05338-01

TABLE A (CONT)

SGR DEMODULATOR COMBINING PANEL		SGR DEM EQUIPPED	
PART NO. 790-03533-	NOMENCLATURE		
-11		1 THRU 4 AND 6	790-05338-01
-12		3, 4, AND 6	790-05338-01
-13	SUMMATION NETWORK CU-1784/FCC-17	2 THRU 4	790-05338-01

TABLE B

ANNULLING NETWORK	FIG.
792-05331-01	C
792-05332-01	D
792-05333-01	E
792-05334-01	E
792-05335-01	F
792-05336-01	D
792-05337-01	G
792-05338-01	C
792-05339-01	C




TABLE H

ATTEN. DB	STRAP AB TERMINALS		
0	A-K		
1	A-B	C-K	
2	A-D	E-K	
3	A-B	C-D	E-K
4	A-F		G-K
5	A-B	C-F	G-K
6	A-D	E-F	G-K
7	A-B	C-D	E-F G-K

TABLE H (CONT)

ATTEN. DB	STRAP AB TERMINALS		
8	A-H		J-K
9	A-B	C-H	J-K
10	A-D	E-H	J-K
11	A-B	C-D	E-H J-K
12	A-F		G-H J-K
13	A-B	C-F	G-H J-K
14	A-D	E-F	G-H J-K
15	A-B	C-D	E-F G-H J-K

Figure 14. Supergroup Combining Panel Diagram




TABLE B

ATTEN, DB	STRAP AB TERMINALS		
0	A-K		
1	A-B	C-K	
2	A-D	E-K	
3	A-B	C-D	E-K
4	A-F		G-K
5	A-B	C-F	G-K
6	A-D	E-F	G-K
7	A-B	C-D	E-F

TABLE B (CONT)

ATTEN, DB [A]	STRAP AB TERMINALS		
8 (12)	A-H		J-K
9 (13)	A-B	C-H	J-K
10 (14)	A-D	E-H	J-K
11 (15)	B	C-D	E-H
12 (16)	A-F		G-H
13 (17)	A-B	C-F	G-H
14 (18)	A-D	E-F	G-H
15 (19)	A-B	C-D	E-F

TABLE A

SGR DEMODULATOR COMBINING PANEL		*INPUT LEVEL, DBM	FREQ RANGE, KC
PART NO. 790-07211-	NOMENCLATURE		
-01	FREQUENCY DIVIDER CU-1273/MCC-13	-10	60-552
-02		-15	
-03		-15	12-552

*HF RCVG LEVEL (TEST TONE) AT WHICH TRANSMISSION TEST SET READS 0 DB.

Figure 15. Supergroup Demodulator Combining Panel (72-Channel), Schematic Diagram




TABLE A

SGR DEMODULATOR COMBINING PANEL		ANNULLING NETWORK	
PART NO. 790-03533-	NOMENCLATURE	SGR DEM EQUIPPED	
-01	COMBINING NETWORK MX-3569/FCC-1.7	1 THRU 10	790-05331-01 790-05332-01
-02	COMBINING NETWORK MX-7516/FCC	1, 2 OR 1 AND 2	NOT USED NOT USED
-03		3 AND 4	790-05333-01 790-05334-01
-04		1 THRU 4	790-05335-01 790-05336-01
-05		1 THRU 3	790-05335-01 NOT USED
-06		2 THRU 5	790-05337-01 790-05336-01
-07		1 THRU 5	790-05339-01 790-05336-01
-08		3	790-05333-01 NOT USED
-09	SUMMATION NETWORK CU-1785/FCC-1.7	2 THRU 6 OR 3 THRU 6	790-05337-01 790-05338-01
-10		1 THRU 6	790-05339-01 790-05338-01

TABLE A (CONT)

SGR DEMODULATOR COMBINING PANEL		ANNULLING NETWORK	
PART NO. 790-03533-	NOMENCLATURE	SGR DEM EQUIPPED	
-11		1 THRU 4 AND 6	790-05335-01 790-05338-01
-12		3, 4, AND 6	790-05333-01 790-05338-01
-13	SUMMATION NETWORK CU-1784/FCC-1.7	2 THRU 4	790-05333-01 790-05336-01

TABLE B

ANNULLING NETWORK	FIG.
792-05331-01	C
792-05332-01	D
792-05333-01	E
792-05334-01	E
792-05335-01	F
792-05336-01	D
792-05337-01	G
792-05338-01	C
792-05339-01	C




TABLE H

ATTEN, DB	STRAP AB TERMINALS	
0	A-K	
1	A-B C-K	
2	A-D E-K	
3	A-B C-D E-K	
4	A-F G-K	
5	A-B C-F G-K	
6	A-D E-F G-K	
7	A-B C-D E-F G-K	

TABLE H (CONT)

ATTEN, DB	STRAP AB TERMINALS	
8	A-H J-K	
9	A-B C-H J-K	
10	A-D E-H J-K	
11	A-B C-D E-H J-K	
12	A-F G-H J-K	
13	A-B C-F G-H J-K	
14	A-D E-F G-H J-K	
15	A-B C-D E-F G-H J-K	

Figure 14. Supergroup Demodulator Combining Panel, Schematic Diagram




Figure 16. Master Frequency Generator Shelf, Schematic Diagram (Sheet 1 of 2)





TABLE A

AC PWR FREQ	OPTIONS		MASTER FREQUENCY GENERATOR		OPTIONAL MODULES			
	OPERATING MODE		SHELF	TRAY	SERVO AMPL A7	PILOT AMPL A8	PHASE DET A9	SERVO A10
60 CPS	MASTER, CONVERTIBLE TO SLAVE	WITH MEMORY	790-05685-01 TA-495/MRC-98	790-05683-01 0A-6791/FCC	790-05115-01	790-05020-01	790-05113-01	790-05695-01 790-07217-01 SEE FIG. C
		WITHOUT MEMORY	790-05685-03	790-05683-03				
400 CPS	MASTER, NON-CONVERTIBLE	WITH MEMORY	790-05155-01 0A-4127/MCC-12	790-05112-01 0A-4128/MCC-12	790-06622-01	790-05020-01	790-05113-01	790-05114-01 790-07217-01 SEE FIG. C
		WITHOUT MEMORY	790-05155-03	790-05112-03				
		MASTER, NON-CONVERTIBLE	790-05155-05	790-05112-05	NOT USED	NOT USED	790-05432-01 SEE FIG. B	NOT USED

Figure 16. Master Frequency Generator and Servo Amplifier (Sheet 2 of 2)






TABLE A

AC PWR FREQ	OPTIONS		MASTER FREQUENCY GENERATOR SHELF		MASTER FREQUENCY GENERATOR TRAY		OPTIONAL MODULES			
	OPERATING MODE						SERVO AMPL A7	PILOT AMPL A8	PHASE DET A9	SERVO A10
60 CPS	MASTER CONVERTIBLE TO SLAVE	WITH MEMORY	790-05685-01	TA-495/MRC-98	790-05683-01	QA-6791/FCC	790-05115-01	790-05020-01	790-05113-01	790-05695-01
		WITHOUT MEMORY	790-05685-03		790-05683-03					790-07217-01
400 CPS	MASTER, NON-CONVERTIBLE	WITH MEMORY	790-05155-01	QA-4127/MCC-12	790-05112-01	QA-4128/MCC-12	790-06622-01	790-05020-01	790-05113-01	790-05114-01
		WITHOUT MEMORY	790-05155-03		790-05112-03					790-07217-01
		MASTER, NON-CONVERTIBLE	790-05155-05		790-05112-05					790-05432-01

Figure 16. Master Frequency Generator Shelf, Schematic Diagram (Sheet 2 of 2)










TABLE A

CHANNEL CARRIER SUPPLY SHELF	
PART NO.	790-01150-01
NOMENCLATURE	TELEPHONE CARRIER FREQUENCY SUPPLY GROUP DA-4126/GCC

Figure 17. Channel Carrier Supply Shelf, Schematic Diagram (Sheet 1 of 2)



649-16697 SH2

Figure 17. Channel Carrier Amplifier Schematic Diagram










Figure 17. Channel Carrier Supply Shelf, Schematic Diagram (Sheet 2 of 2)





OPTIONAL STRAPPING. REFER TO CHAPTER 2 OF SERVICE MANUAL.

TABLE A

CHANNEL CARRIER AMPLIFIER SHELF	
PART NO.	790-01261-01
NOMENCLATURE	AMPLIFIER-CONTROL GROUP 0A-6119/MCC-13

Figure 18. Channel Carrier Amplifier Schematic Diagram






Figure 18. Channel Carrier Amplifier Shelf, Schematic Diagram (Sheet 2 of 2)



OPTIONAL STRAPPING. REFER TO CHAPTER 2 OF SERVICE MANUAL.

TABLE A

CHANNEL CARRIER AMPLIFIER SHELF	
PART NO.	790-01261-01
NOMENCLATURE	AMPLIFIER-CONTROL GROUP 0A-6119/MCC-13

Figure 18. Channel Carrier Amplifier Shelf, Schematic Diagram (Sheet 1 of 2)




Figure 18. Channel Carrier Amplifier Schematic Diagram (Sheet 2)





TABLE A

GROUP CARRIER GENERATOR SHELF	
PART NO.	790-02152-01
NOMENCLATURE	TELEPHONE CARRIER FREQUENCY SUPPLY GROUP OA-4110 / GCC

Figure 19. Group Carrier Generator Shelf, Schematic Diagram (Sheet 1 of 2)






Figure 19. Group Carrier Generator Shelf, Schematic Diagram (Sheet 2 of 2)








TABLE A

GROUP CARRIER SUPPLY SHELF	
PART NO.	790-02199-01
NOMENCLATURE	TELEPHONE CARRIER FREQUENCY SUPPLY GROUP 0A-41 I3/GCC

Figure 20. Group Carrier Supply Shelf, Schematic Diagram (Sheet 1 of 2)



849-16700 SH 2












Figure 20. Group C Schemat



849-16700 SH 1





TABLE A

GROUP CARRIER SUPPLY SHELF	
PART NO.	790-02199-01
NOMENCLATURE	TELEPHONE CARRIER FREQUENCY SUPPLY GROUP OA-4113/GCC








Figure 20. Group Carrier Supply Shelf, Schematic Diagram (Sheet 2 of 2)



849-16701 SH 1





TABLE A

GROUP CARRIER AMPLIFIER SHELF	
PART NO.	790-04072-01
NOMENCLATURE	RADIO FREQUENCY AMPLIFIER GROUP AM-3157/FCC-17

Figure 21. Group Carrier Amplifier Shelf, Schematic Diagram (Sheet 1 of 2)













Figure 21. Group Carrier Amplifier Shelf, Schematic Diagram (Sheet 2 of 2)



849-16701 SH 1



GROUP CARRIER	
PART NO.	7
NOMENCLATURE	R A





TABLE A
 SUPERGROUP CARRIER GENERATOR SHELF

PART NO.	790-0288-01
NOMENCLATURE	TELEPHONE CARRIER FREQUENCY SUPPLY GROUP TA-418/FCC-17

Figure 22. Supergroup Carrier Generator Shelf, Schematic Diagram




849-16703 SH 1

TABLE A

SUPERGROUP CARRIER SUPPLY SHELF	
PART NO.	790-02880-01
NOMENCLATURE	RADIO FREQUENCY AMPLIFIER GROUP AM-2995/FCC-17

Figure 23. Supergroup Carrier Supply Shelf, Schematic Diagram (Sheet 1 of 3)






TABLE A

SUPERGROUP CARRIER SUPPLY SHELF	
PART NO.	790-02880-01
NOMENCLATURE	RADIO FREQUENCY AMPLIFIER GROUP AM-2995/FCC-17

Figure 23. Supergroup Carrier Supply Shelf, Schematic Diagram (Sheet 1 of 3)












Figure 23. Supergroup Carrier Supply Shelf, Schematic Diagram (Sheet 2 of 3)





OPTIONAL STRAP OF SERVICE MANU

Figure 23.



849-16703 SH 2



OPTIONAL STRAPPING. REFER TO CHAPTER 2 OF SERVICE MANUAL.





Figure 23. Supergroup Carrier Supply Shelf, Schematic Diagram (Sheet 3 of 3)





TABLE B

SGR CARR FREQ, KC	PARALLELING NETWORK			AMPLIFIER			SHELF		
	PART NO. 790-	R3 OHMS	R4 OHMS	PART NO. 790-	GAIN DB	LOAD DC MA	RA OHMS	INPUT LEVEL	OUTPUT LEVEL
564	04973-01	-	-	04660-01	36	28	1100	0.13V	0.95V
612	04972-01	-	-	-	-	-	-	-	-
1116	04236-01	178	121	02330-01	33	29	1330	0.23V	0.95V
1364	04237-01	178	121	-	-	-	-	-	-
1612	04238-01	178	121	-	-	-	-	-	-
1860	04239-01	196	121	-	-	-	-	-	-
2108	04240-01	196	121	-	-	-	-	-	-
2356	04241-01	196	121	-	-	-	-	-	-
2604	04242-01	215	110	-	-	-	-	-	-
2852	04243-01	215	110	-	-	-	-	-	-










TABLE A

SUPERGROUP CARRIER AMPLIFIER SHELF	
PART NO.	790-04971-01
NOMENCLATURE	AMPLIFIER-RELAY GROUP 0A-7320/UCC-4(V)

Figure 24. Supergroup Carrier Amplifier Shelf, Schematic Diagram (Sheet 1 of 2)

OPTIONAL STRAPPING. REFER TO CHAPTER 2 OF SERVICE MANUAL.



849-16704 SHI

OPTIONAL STRAPPING. REFER TO CHAPTER 2 OF SERVICE MANUAL.







Figure 24. Supergroup Carrier Amplifier Shelf, Schematic Diagram (Sheet 2 of 2)




Figure 25. Power Supply Shelf, Schematic Diagram




TABLE A

FUSE PANEL		USED ON
PART NUMBER	NOMENCLATURE: FUSE PANEL	
790-03307-01	SB-1298/FCC-17	AN/FCC-17
790-03349-01	SB-1296/FCC-17	
790-03358-01	SB-1276/FCC-17	
790-03360-01	SB-1297/FCC-17	
790-03362-01	SB-1294/FCC-17	
790-11501-01	SB-2932/FCC	AN/FCC-22
790-11502-01	SB-2922/FCC	MISC
790-11571-01	SB-2924/FCC	AN/FCC-21, -22
790-11574-01	SB-2921/FCC	AN/FCC-21
790-12601-01	SB-2931/FCC	AN/FCC-22
790-12604-01	SB-3078/UCC-4(V)	MISC

*SCHEMATICS ARE IN NUMERICAL ORDER BY FUSE PANEL PART N

TABLE B

INDICATOR ALARM FUSES

*RATING, AMPERES	COLOR CODE	TYPE
0.18	YELLOW	70E
0.25	VIOLET	70F
0.25	VIOLET-WHITE	70K
0.50	RED	70G
0.75	TAN	70H
1.33	WHITE	70A
2.00	ORANGE	70B
3.00	BLUE	70C
5.00	GREEN	70D
6.00	GREEN-WHITE	71A

*FUSE WILL CARRY 100% OF RATED CURRENT CONTINUOUSLY. AT 150% OF RATED CURRENT, FUSE WILL BLOW WITHIN 90 SECONDS (300 SECONDS FOR TYPE 70K).

Figure 26. Fuse Panels, Schematic Diagram (Sheet 1)







TABLE A

AC POWER FREQ, CPS	POWER SUPPLY SHELF			POWER SUPPLY TRAY	
	PART NO.	NOMENCLATURE	QTY	PART NO.	NOMENCLATURE
50-60	790-07975-01	POWER SUPPLY ASSEMBLY OA-6445/FCC	2	790-07974-01	POWER SUPPLY PP-3965/FCC
	790-07975-03		1		
60	790-01855-01	POWER SUPPLY SET OA-6830/FCC	2	790-01866-01	POWER SUPPLY PP-4115/FCC
	790-01855-03	POWER SUPPLY PP-3613/MRC-98	1		
400	790-02963-01	POWER SUPPLY SET OA-4109/MCC-12	2	790-02964-01	POWER SUPPLY PP-3498/MCC-12

- NOTES:**
- THIS DIAGRAM REPRESENTS THE 60-CPS OR 50-60 CPS POWER SUPPLY SHELF. FOR THE 400-CPS POWER SUPPLY SHELF, MAKE THE FOLLOWING CHANGES TO THE CIRCUITS SHOWN FOR THE POWER SUPPLY TRAYS:
 - USE FIGURE B FOR THE 100-UF FILTER CAPACITORS IN A1.
 - USE FIGURE C FOR SATURABLE REACTOR L1 AND ASSOCIATED CIRCUITS (SEE NOTE 2.)
 - ADD 450-OHM LOAD RESISTORS A5R1 AND A5R2 IN PARALLEL WITH A4R1.
 - IN THE 60-CPS AND 50-60 CPS POWER SUPPLY TRAYS, THE SATURABLE REACTOR IS DESIGNATED L1. IN THE 400-CPS POWER SUPPLY TRAY, TWO 450-OHM LOAD RESISTORS (R1 AND R2) ARE MOUNTED ON L1 AND THE COMBINATION IS ASSIGNED THE SUBASSEMBLY DESIGNATION A5.
 - THE DC RESISTANCE OF EACH WINDING OF TRANSFORMER T1 IS APPROXIMATELY 1 OHM.



849-16705

MONITOR-REGULATOR
790-06961-01

MONITOR-REGULATOR
790-06961-01

SAME AS A1




TABLE A

FUSE PANEL		USED ON	*SCHEM ON SHEET
PART NUMBER	NOMENCLATURE: FUSE PANEL		
790-03307-01	SB-1298/FCC-17	AN/FCC-17	1
790-03349-01	SB-1296/FCC-17		
790-03358-01	SB-1276/FCC-17		
790-03360-01	SB-1297/FCC-17		
790-03362-01	SB-1294/FCC-17		
790-03364-01	SB-1295/FCC-17	AN/FCC-22	2
790-11501-01	SB-2932/FCC		
790-11502-01	SB-2922/FCC		
790-11571-01	SB-2924/FCC		
790-11574-01	SB-2921/FCC		
790-12601-01	SB-2931/FCC		
790-12604-01	SB-3078/UCC-4(V)		

*SCHEMATICS ARE IN NUMERICAL ORDER BY FUSE PANEL PART NUMBER.

TABLE B

INDICATOR ALARM FUSES

*RATING, AMPERES	COLOR CODE	TYPE
0.18	YELLOW	70E
0.25	VIOLET	70F
0.25	VIOLET-WHITE	70K
0.50	RED	70G
0.75	TAN	70H
1.33	WHITE	70A
2.00	ORANGE	70B
3.00	BLUE	70C
5.00	GREEN	70D
6.00	GREEN-WHITE	71A

*FUSE WILL CARRY 100% OF RATED CURRENT CONTINUOUSLY. AT 150% OF RATED CURRENT, FUSE WILL BLOW WITHIN 90 SECONDS (300 SECONDS FOR TYPE 70K).

Figure 26. Fuse Panels, Schematic Diagram (Sheet 1 of 2)









Figure 26. Fuse Panels, Schematic Diagram (Sheet 2 of 2)










Figure 27. Master Alarm Panel, Schematic Diagram






Figure 27. Master Alarm Panel, Schematic Diagram





Figure 28. Handset and Handset Patch Panel, Schematic Diagram



849-16709 SH 1

NOTES:

- THIS DIAGRAM SHOWS INTRA-RACK WIRING, INTER-RACK WIRING (BETWEEN RACKS), AND WIRING TO EXTERNAL EQUIPMENT. THE SHEET NUMBER OR FIGURE NUMBER OF THE DIAGRAM PERTAINING TO EACH MAJOR COMPONENT IS SHOWN IN THE EQUIPMENT RACK LAYOUT ON THIS SHEET.
- INTRA-RACK WIRING TO THE EQUIPMENT SHELVES (AND TRAYS) IS PROVIDED BY WIRING HARNESES THAT PLUG INTO RECEPTACLES AT THE REAR OF THE SHELVES. THE PART NUMBERS OF THE WIRING HARNESES ARE CALLED OUT ON THIS DIAGRAM AT THE PLUG END.
- PANELS AND JACKFIELDS HAVE INTEGRAL WIRING HARNESES THROUGH WHICH CONNECTIONS ARE MADE TO THE TERMINAL BOARD PANELS AT THE TOP OF THE RACK.
- UNLESS OTHERWISE SPECIFIED, INTRA-RACK WIRING IS 22 AWG. COAXIAL CABLE IS TYPE RG-187A/U. THE SIZE OF WIRE IN THE WIRING HARNESES IS INDICATED AT THE END ADJACENT TO THE SHELF, TRAY, OR PANEL.
- WIRE COLOR ABBREVIATIONS.
BK BLACK GY GRAY W WHITE
BL BLUE O ORANGE Y YELLOW
BR BROWN R RED
G GREEN V VIOLET
- THE SYMBOL — 2 — MEANS THAT THE SINGLE LINE REPRESENTS TWO SEPARATE WIRES OR CABLES OF THE SAME TYPE.
- INTER-RACK AND EXTERNAL WIRING IS IDENTIFIED BY THE FOLLOWING SYMBOLS:
② INTER-RACK WIRING TO OR FROM THE NUMBERED RACK, (TO AND FROM DENOTE THE DIRECTION OF SIGNAL FLOW.)
⊗ WIRING TO OR FROM EXTERNAL EQUIPMENT
⊙ OPTIONAL CIRCUITS THAT MAY BE USED TO SUPPLY CARRIERS, SYNC PILOTS, DC POWER, ALARM CIRCUIT POWER, OR ALARM FUNCTIONS TO ADJACENT MULTIPLEXER SETS OR AUXILIARY EQUIPMENT.
- FOR DESIGNATION OF WIRE USED IN INTER-RACK AND EXTERNAL WIRING, REFER TO CHAPTER 2 OF THE SERVICE MANUAL.








Figure 29. Mu... Cal...









Figure 29. Multiplexer Set AN/FCC-21, Cabling Diagram (Sheet 1 of 7)










Figure 29. Multiplexer Set AN/FCC-21, Cabling Diagram (Sheet 2 of 7)










Figure 29. Multiplexer Set AN/FCC-21, Cabling Diagram (Sheet 2 of 7)



849-16709 SH 3











Figure 29. Multiplexer Set AN/FCC-21, Cabling Diagram (Sheet 3 of 7)

FIG. 4A
TERMINAL BOARD AITB1
RACK 1



849-16709 SH 4

FIG. 4B
TERMINAL BOARD AITB2
RACK 1





FIG. 7A
TERMINAL BOARD A2TB1
RACK 2




FIG. 7B
TERMINAL BOARD A2TB2
RACK 2





FIG. 7C
TERMINAL BOARD A2TB3
RACK 2




849-16709 SH 7

THIS SHEET CHANNEL EQUIP. RACK 2 TB PANEL A2





Figure 29. Multiplexer Set AN/FCC-5 Cabling Diagram (Sheet 7)

FIG. 6A
 TERMINAL BOARD AITB1
 RACK 2






849-16709 SH 6

FIG. 6B
 TERMINAL BOARD AITB2
 RACK 2




TO VF RCVG EQUIPMENT



THIS SHEET CHANNEL EQUIP. RACK 2
TB PANEL A2

Figure 29. Multiplexer Set AN/FCC-21, Cabling Diagram (Sheet 7 of 7)



A POWER SUPPLY SHELF AND GROUP PILOT ALARM SHELF ARE NOT USED ON RACKS 4 AND 6.
B RACK 3 HAS A CHANNEL CARRIER SUPPLY SHELF (FIG. 3E) INSTEAD OF A CHANNEL CARRIER AMPLIFIER SHELF.

- WIRE COLOR ABBREVIATIONS.
 BK BLACK GY GRAY W WHITE
 BL BLUE O ORANGE Y YELLOW
 BR BROWN R RED
 G GREEN V VIOLET
- THE SYMBOL $\text{---}2\text{---}$ MEANS THAT THE SINGLE LINE REPRESENTS TWO SEPARATE WIRES OR CABLES OF THE SAME TYPE.
- INTER-RACK AND EXTERNAL WIRING IS IDENTIFIED BY THE FOLLOWING SYMBOLS.
 $\text{---}2\text{---}$ INTER-RACK WIRING TO OR FROM THE NUMBERED RACK. (TO AND FROM DENOTE THE DIRECTION OF SIGNAL FLOW.)
 $\text{---}X\text{---}$ WIRING TO OR FROM EXTERNAL EQUIPMENT.
 $\text{---}O\text{---}$ OPTIONAL CIRCUITS THAT MAY BE USED TO SUPPLY CARRIERS, SYNC PILOTS, DC POWER, ALARM CIRCUIT POWER, OR ALARM FUNCTIONS TO ADJACENT MULTIPLEXER SETS OR AUXILIARY EQUIPMENT.
- FOR DESCRIPTION OF WIRE AND CABLE USED IN INTER-RACK AND EXTERNAL WIRING, REFER TO CHAPTER 2 OF THE SERVICE MANUAL.










Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 1 of 15)



849-16710 SH 2











Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 2 of 15)



NOTES:

- THIS DIAGRAM SHOWS INTRA-RACK WIRING, INTER-RACK WIRING (BETWEEN RACKS), AND WIRING TO EXTERNAL EQUIPMENT. THE SHEET NUMBER OR FIGURE NUMBER OF THE DIAGRAM PERTAINING TO EACH MAJOR COMPONENT IS SHOWN IN THE EQUIPMENT RACK LAYOUT ON THIS SHEET.
- INTRA-RACK WIRING TO THE EQUIPMENT SHELVES (AND TRAYS) IS PROVIDED BY WIRING HARNESES THAT PLUG INTO RECEPTACLES AT THE REAR OF THE SHELVES. THE PART NUMBERS OF THE WIRING HARNESES ARE CALLED OUT ON THIS DIAGRAM AT THE PLUG END.
- PANELS AND JACKFIELDS HAVE INTEGRAL WIRING HARNESES THROUGH WHICH CONNECTIONS ARE MADE TO THE TERMINAL BOARD PANELS AT THE TOP OF THE RACK.
- UNLESS OTHERWISE SPECIFIED, INTRA-RACK WIRING IS 22 AWG. COAXIAL CABLE IS TYPE RG-187A/U. THE SIZE OF WIRE IN THE WIRING HARNESES IS INDICATED AT THE END ADJACENT TO THE SHELF, TRAY, OR PANEL.

5. WIRE COLOR ABBREVIATIONS.

BK	BLACK	GY	GRAY	W	WHITE
BL	BLUE	O	ORANGE	Y	YELLOW
BR	BROWN	R	RED		
G	GREEN	V	VIOLET		

- THE SYMBOL MEANS THAT THE SINGLE LINE REPRESENTS TWO SEPARATE WIRES OR CABLES OF THE SAME TYPE.
- INTER-RACK AND EXTERNAL WIRING IS IDENTIFIED BY THE FOLLOWING SYMBOLS.

- INTER-RACK WIRING TO OR FROM THE NUMBERED RACK. (TO AND FROM DENOTE THE DIRECTION OF SIGNAL FLOW.)
- WIRING TO OR FROM EXTERNAL EQUIPMENT.

- OPTIONAL CIRCUITS THAT MAY BE USED TO SUPPLY CARRIERS, SYNC PILOTS, DC POWER, ALARM CIRCUIT POWER, OR ALARM FUNCTIONS TO ADJACENT MULTIPLEXER SETS OR AUXILIARY EQUIPMENT.
- FOR DESCRIPTION OF WIRE AND CABLE USED IN INTER-RACK AND EXTERNAL WIRING, REFER TO CHAPTER 2 OF THE SERVICE MANUAL.





FIG. 2D
SUPERGROUP JACKFIELD
RACK 2




FIG. 10C

FIG. 10C

FIG. 2E
SUPERGROUP DEMODULATOR COMBINING PANEL
RACK 2




FIG. 10A

FIG. 2C, SGR DEM

FIG. 10A

FIG. 2F
MASTER FREQUENCY GENERATOR SHELF
RACK 1




FIG. 6C

FIG. 6B

FIG. 6A

FIG. 4C

AC PWR

DISTR BOX

FIG. 2G

SUPERGROUP CARRIER GENERATOR SHELF
RACK 1




FIG. 6A

FIG. 6C

FIG. 6B

FIG. 2H
SUPERGROUP CARRIER AMPLIFIER SHELF
RACK 1




FIG. 6C

FIG. 6B

FIG. 7A

FIG. 7C

Figure 30. Multiplexer Set AN/FCC-22,
Cabling Diagram (Sheet 2 of 15)









Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 3 of 15)











FIG. 4E (NOT USED)

Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 4 of 15)









Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 3 of 15)

FIG. 5A
TERMINAL BOARD A1TB1
RACK 1





FIG. 5B
TERMINAL BOARD A1TB2
RACK 1



[B] AS REQUIRED, RUN JUMPER TO TERMINAL BOARD A3TB1 (FIG. 7A) TO FURNISH SGR CARRIER TO INPUTS OF SGR CARRIER AMPLIFIER SHELF.

FIG. 5C
TERMINAL BOARD A1TB3
RACK 1






FIG. 5D
TERMINAL BOARD A1TB3
RACK 1



THIS SHEET COMMON EQUIP. RACK 1 TB PANEL A1

Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 5 of 15)

FIG. 5A
 TERMINAL BOARD A1TB1
 RACK 1



849-16710 SH 5

FIG. 5B
 TERMINAL BOARD A1TB2
 RACK 1





FIG. 5B
 TERMINAL BOARD A1TB2
 RACK 1



AS REQUIRED, RUN JUMPER TO TERMINAL BOARD A3TB1 (FIG. 7A) TO FURNISH SGR CARRIER TO INPUTS OF SGR CARRIER AMPLIFIER SHELF.

FIG. 7A
TERMINAL BOARD A3TB1
RACK 1




FIG. 2H
SGR CARR AMPL

849-16710 SH 7

B AS REQUIRED, CONNECT JUMPER FROM TERMINAL BOARD A1TB2 (FIG. 5B) OR A1TB3 (FIG. 5C) TO FURNISH SGR CARRIER TO INPUTS OF SGR CARRIER AMPLIFIER SHELF.

FIG. 7B
TERMINAL BOARD A3TB2
RACK 1




FIG. 2H
SGR CARR AMPL

NOT USED

NOT USED

FIG. 7C
TERMINAL BOARD A3TB3
RACK 1




FIG. 2H
SGR CARR AMPL




FIG. 2H
SGR CARR AMPL

THIS SHEET COMMON EQUIP. RACK 1
TB PANEL A3

Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 7 of 15)

FIG. 8A
TERMINAL BOARD AITB1
RACK 2




FIG. 1B
GR RCVG
JACKFIELD




FIG. 1B
GR RCVG
JACKFIELD

FIG. 8B
TERMINAL BOARD AITB2
RACK 2




FIG. 8C
TERMINAL BOARD AITB3
RACK 2




FIG. 1B
GR XMTG
JACKFIELD




FIG. 1B
GR XMTG
JACKFIELD

THIS SHEET GR/SGR EQUIP. RACK 2 TB PANEL A1

Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 8 of 15)






Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 9 of 15)







Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 9 of 15)

FIG. 10A
TERMINAL BOARD A3TB1
RACK 2



849-16710 SH 10

FIG. 10B
TERMINAL BOARD A3TB2
RACK 2






FIG. 10C
TERMINAL BOARD A3TB3
RACK 2



THIS SHEET GR/SGR EQUIP. RACK 2 TB PANEL A3

Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 10 of 15)

FIG. 10A
TERMINAL BOARD A3TB1
RACK 2



849-16710 SH 10

FIG. 10B
TERMINAL BOARD A3TB2
RACK 2




FIG. 10C
TERMINAL BOARD A3TB3
RACK 2





FIG. 10D
TERMINAL BOARD A3TB4
RACK 2



THIS SHEET GR/SGR EQUIP. RACK 2
TB PANEL A3

Figure 30. Multiplexer Set AN/FCC-22,
Cabling Diagram (Sheet 10 of 15)






Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 9 of 15)

FIG. 11A
TERMINAL BOARD AITB1
RACKS 3 THRU 6




FIG. 1A
CHAN MX 1

FIG. 1A
CHAN MX 2

FIG. 1A
CHAN MX 3

FIG. 11B
TERMINAL BOARD AITB2
RACKS 3 THRU 6




FIG. 1A
CHAN MX 3

FIG. 1A
CHAN MX 4

FIG. 1A
CHAN MX 5

FIG. 11C
TERMINAL BOARD AITB3
RACKS 3 THRU 6




FIG. 2A
CHAN DMX 1

FIG. 2A
CHAN DMX 2

FIG. 2A
CHAN DMX 3

FIG. 8C

FIG. 8A

FIG. 1A
CHAN MX

FIG. 2A
CHAN DMX

TO VF RCVG
EQUIPMENT

TO VF RCVG
EQUIPMENT





FIG. 2A
CHAN DMX 3

FIG. 2A
CHAN DMX 4

FIG. 2A
CHAN DMX 5

THIS SHEET CHANNEL EQUIP. RACKS 3 THRU 6
TB PANEL A1

Figure 30. Multiplexer Set AN/FCC-22,
Cabling Diagram (Sheet 11 of 15)



THIS SHEET CHANNEL EQUIP. RACK 3 TB PANEL A2

Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 12 of 15)




Figure 30. Multiplexer Set AN/FCC-22, Cabling Diagram (Sheet 13 of 15)

FIG. 14A
TERMINAL BOARD A2TB1
RACK 5





FIG. 14B
TERMINAL BOARD A2TB2
RACK 5




A WHEN A CHANNEL DEMULTIPLEXER SHELF IS NOT EQUIPPED ON THE RACK, THE ASSOCIATED ALARM CONTROL IN THE GROUP PILOT ALARM SHELF CAN BE DISABLED BY REMOVING THE ALARM RELAY OR BY STRAPPING 64 KC AND DC POWER (-48V AND GRD) TO THE MONITOR CIRCUIT AS FOLLOWS.

CHAN DMX	64 KC, STRAP A2TB1	DC POWER, STRAP A2TB3
1	91-101, 92-102	181-233, 182-234
2	91-103, 92-104	183-235, 184-236
3	91-105, 92-106	185-237, 186-238
4	91-107, 92-108	187-239, 188-240
5	91-109, 92-110	189-241, 190-242


B RESISTORS ON A2TB1 ARE 1/4 WATT, ±1% TOLERANCE, PER MIL-R-10509.

FIG. 14C
TERMINAL BOARD A2TB3
RACK 5



THIS SHEET CHANNEL EQUIP. RACK 5
TB PANEL A2

Figure 30. Multiplexer Set AN/FCC-22,
Cabling Diagram (Sheet 14 of 15)



849-16711 SH 1


NOTES:

- THIS DIAGRAM SHOWS INTRA-RACK WIRING, INTER-RACK WIRING (BETWEEN RACKS), AND WIRING TO EXTERNAL EQUIPMENT. THE SHEET NUMBER OR FIGURE NUMBER OF THE DIAGRAM PERTAINING TO EACH MAJOR COMPONENT IS SHOWN IN THE EQUIPMENT RACK LAYOUT ON THIS SHEET.
- INTRA-RACK WIRING TO THE EQUIPMENT SHELVES (AND TRAYS) IS PROVIDED BY WIRING HARNESSSES THAT PLUG INTO RECEPTACLES AT THE REAR OF THE SHELVES. THE PART NUMBERS OF THE WIRING HARNESSSES ARE CALLED OUT ON THIS DIAGRAM AT THE PLUG END.
- PANELS AND JACKFIELDS HAVE INTEGRAL WIRING HARNESSSES THROUGH WHICH CONNECTIONS ARE MADE TO THE TERMINAL BOARD PANELS AT THE TOP OF THE RACK.
- UNLESS OTHERWISE SPECIFIED, INTRA-RACK WIRING IS 22 AWG. COAXIAL CABLE IS TYPE RG-187A/U. THE SIZE OF THE WIRING HARNESSSES IS INDICATED AT THE END ADJACENT TO THE SHELF, TRAY, OR PANEL.
- WIRE COLOR ABBREVIATIONS.

BK	BLACK	GY	GRAY	W	WHITE
BL	BLUE	O	ORANGE	Y	YELLOW
BR	BROWN	R	RED		
G	GREEN	V	VIOLET		
- THE SYMBOL $\text{---}2\text{---}$ MEANS THAT THE SINGLE LINE REPRESENTS TWO SEPARATE WIRES OR CABLES OF THE SAME TYPE.
- INTER-RACK AND EXTERNAL WIRING IS IDENTIFIED BY THE FOLLOWING SYMBOLS.
 - (Z) INTER-RACK WIRING TO OR FROM THE NUMBERED RACK. (TO AND FROM DENOTE THE DIRECTION OF SIGNAL FLOW.)
 - (X) WIRING TO OR FROM EXTERNAL EQUIPMENT.
 - (O) OPTIONAL CIRCUITS THAT MAY BE USED TO SUPPLY CARRIERS, SYNC PILOTS, DC POWER, ALARM CIRCUIT POWER, OR ALARM FUNCTIONS TO ADJACENT MULTIPLEXER SETS OR AUXILIARY EQUIPMENT.
- FOR DESCRIPTION OF WIRE AND CABLE USED IN INTER-RACK AND EXTERNAL WIRING, REFER TO CHAPTER 2 OF THE SERVICE MANUAL.

Figure 31. M
C

FIG. 15A
 TERMINAL BOARD A2TB1
 RACK 6



849-16710 SH 15




FIG. 1A CHAN MX
 FIG. 2A CHAN DMX
 FIG. 3F CHAN CARR AMPL
 TO FIG. 14B

13
EQUIPMENT
PANEL
17
PANEL
18 (RACK 5)
19
349-01
6C
SHELF
5D
ER
LF
LEXER
4C
3E
5C
LEXER
3E








Figure 31. Multiplexer Set AN/FCC-17, Cabling Diagram (Sheet 1 of 19)

FIG. 2A
UPPER SECTION
GR XMTG JACKFIELD, RACK 2
GR RCVG JACKFIELD, RACK 3

GR MX IN	GROUP XMTG	CHAN MX OUT
GR DMX OUT	GROUP RCVG	CHAN DMX IN





FIG. 9B, 12B

GR MX IN	GROUP XMTG	CHAN MX OUT
GR DMX OUT	GROUP RCVG	CHAN DMX IN




FIG. 9C, 12C

GR MX IN	GROUP XMTG	CHAN MX OUT
GR DMX OUT	GROUP RCVG	CHAN DMX IN




FIG. 2B
LOWER SECTION
GR XMTG JACKFIELD, RACK 2
GR RCVG JACKFIELD, RACK 3

GR MX IN	GROUP XMTG	CHAN MX OUT
GR DMX OUT	GROUP RCVG	CHAN DMX IN







Figure 31. Multiplexer Set AN/FCC-17, Cabling Diagram (Sheet 2 of 19)



849-16711 SH 3







Figure 31. Multiplexer Set AN/FCC-17, Cabling Diagram (Sheet 3 of 19)




FIG. 9A, 12A

FIG. 9A, 12A




FIG. 9A, 12A

FIG. 9A, 12A




FIG. 9B, 12B

FIG. 9B, 12B




FIG. 9B, 12B

FIG. 9B, 12B

FIG. 9C, 12C

FIG. 9C, 12C






Figure 31. Multiplexer Set AN/FCC-17, Cabling Diagram (Sheet 3 of 19)










Figure 31. Multiplexer Set AN/FCC-17, Cabling Diagram (Sheet 4 of 19)

FIG. 5A
SUPERGROUP CARRIER GENERATOR SHELF
RACK 1



849-16711 SH 5

FIG. 5B
SUPERGROUP CARRIER SUPPLY SHELF
RACK 1




FIG. 5C
GROUP PILOT ALARM SHELF
RACK 5, 7, 9, 11, 13




FIG. 5D
POWER SUPPLY SHELF
RACK 1, 5, 7, 9, 11, 13




FIG. 5E
MASTER ALARM PANEL
RACK 1





Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 5 of 19)

FIG. 7A
TERMINAL BOARD AITB1
RACK 1



849-16711 SH 7

FIG. 7B
TERMINAL BOARD AITB2
RACK 1






FIG. 7C
TERMINAL BOARD AITB3
RACK 1



THIS SHEET COMMON EQUIP. RACK 1
TB PANEL A1

Figure 31. Multiplexer Set AN/F...
Cabling Diagram (Sheet 1)

FIG. 7B
TERMINAL BOARD AITB2
RACK 1






FIG. 7C
TERMINAL BOARD AITB3
RACK 1



THIS SHEET COMMON EQUIP. RACK 1
TB PANEL A1

Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 7 of 19)

FIG. 6A
FUSE PANEL 790-03360-01
RACK 1




FIG. 6C
FUSE PANEL 790-03349-01
RACK 5,7,9,11,13




FIG. 6E
AC POWER DISTRIBUTION BOX
RACK 5,7,9,11,13




FIG. 6F
FUSE PANEL 790-03364-01
RACK 2




FIG. 6B
FUSE PANEL 790-03362-01
RACK 1




FIG. 6D
FUSE PANEL 790-03358-01
RACK 4,6,8,10,12




FIG. 9A
TERMINAL BOARD AITB1
RACK 2




FIG. 9B
TERMINAL BOARD AITB2
RACK 2




FIG. 9C
TERMINAL BOARD AITB3
RACK 2





FIG. 9D
TERMINAL BOARD AITB3
RACK 2



849-16711 SH 9

THIS SHEET GR/TB

Figur

FIG. 9B
TERMINAL BOARD AITB2
RACK 2




FIG. 9C
TERMINAL BOARD AITB3
RACK 2





FIG. 9D
TERMINAL BOARD AITB4
RACK 2



THIS SHEET GR/SGR MX EQUIP. RACK 2
TB PANEL A1

Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 9 of 19)






Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 10 of 19)

FIG. 11A
TERMINAL BOARD A3TB1
RACK 2




FIG. 11B
TERMINAL BOARD A3TB2
RACK 2





FIG. 11C
TERMINAL BOARD A3TB3
RACK 2





Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 11 of 19)

FIG. 12A
TERMINAL BOARD AITB1
RACK 3






FIG. 12B
TERMINAL BOARD AITB2
RACK 3







FIG. 12C
TERMINAL BOARD AITB3
RACK 3



THIS SHEET GR/SGR DMX EQUIP. RACK 3 TB PANEL A1

Figure 31. Multiplexer Set AN/FCC-17, Cabling Diagram (Sheet 12 of 19)

FIG. 13A
TERMINAL BOARD A2TB1
RACK 3




FIG. 13B
TERMINAL BOARD A2TB2
RACK 3






FIG. 13C
TERMINAL BOARD A2TB3
RACK 3



THIS SHEET GR/SGR DMX EQUIP. RACK 3
TB PANEL A2

Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 13 of 19)

FIG. 12A
TERMINAL BOARD AITB1
RACK 3



849-16711 SH 12

FIG. 12A
TERMINAL BOARD AITB1
RACK 3









FIG. 12B
TERMINAL BOARD AITB2
RACK 3





THIS SHEET GR/SGR DMX EQUIP. RACK 3
TB PANEL A2

Figure 31. Multiplexer Set AN/FCC-17, Cabling Diagram (Sheet 13 of 19)

FIG. 14A
TERMINAL BOARD A3TB1
RACK 3




FIG. 14B
TERMINAL BOARD A3TB2
RACK 3




FIG. 14C
TERMINAL BOARD A3TB3
RACK 3






Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 14 of 19)

FIG. 14A
 TERMINAL BOARD A3TB1
 RACK 3



849-16711 SH 14

FIG. 14B
 TERMINAL BOARD A3TB2
 RACK 3





FIG. 3B SGR DEM 1

FIG. 3D GR DMX 1

FIG. 3B SGR DEM 2

FIG. 3D GR DMX 2

FIG. 3B SGR DEM 3

FIG. 3D GR DMX 3

FIG. 3B SGR DEM 4

FIG. 3D GR DMX 4

FIG. 3B SGR DEM 5

FIG. 3D GR DMX 5

FIG. 15B
TERMINAL BOARD AITB2
RACK 4,6,8,10,12








FIG. 15C
TERMINAL BOARD AITB3
RACK 4,6,8,10,12



THIS SHEET CHAN MX EQUIP. RACK 4, 6, 8, 10, 12
TB PANEL A1

Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 15 of 19)



THIS SHEET CHAN MX EQUIP. RACK 4, 6, 8, 10, 12 TB PANEL A2

Figure 31. Multiplexer Set AN/FCC-17, Cabling Diagram (Sheet 16 of 19)

FIG. 17B
TERMINAL BOARD AITB2
RACK 5,7,9,11,13







FIG. 17C
TERMINAL BOARD AITB3
RACK 5,7,9,11,13



THIS SHEET CHAN DMX EQUIP. RACK 5, 7, 9, 11, 13
TB PANEL A1

Figure 31. Multiplexer Set AN/FCC-17,
Cabling Diagram (Sheet 17 of 19)

FIG. 16A
 TERMINAL BOARD A2TB1
 RACK 4,6,8,10,12



INTER-RACK CONNECTIONS FOR CHANNEL CARRIER DISTRIBUTION

SYMBOL	CHANNEL MULTIPLEX EQUIPMENT RACK				
	4	6	8	10	12
(E)	(5) FIG. 18A	(5) FIG. 18A	(7) FIG. 19A	(9) FIG. 19A	(11) FIG. 19A
(F)	NO CONNECTION	(7) FIG. 19A	(9) FIG. 19A	(11) FIG. 19A	(13) FIG. 19A

INTER-RACK CONNECTIONS FOR ALARM AND POWER DISTRIBUTION

SYMBOL	CHANNEL MULTIPLEX EQUIPMENT RACK				
	4	6	8	10	12
(J)	(1) FIG. 8B	(4) FIG. 16B	(6) FIG. 16B	(8) FIG. 16B	(10) FIG. 16B
(K)	(6) FIG. 16B	(8) FIG. 16B	(10) FIG. 16B	(12) FIG. 16B	NO CONNECTION
(L)	(5) FIG. 18C	(7) FIG. 19C	(9) FIG. 19C	(11) FIG. 19C	(13) FIG. 19C

FIG. 16B
 TERMINAL BOARD A2
 RACK 4,6,8,10,12





FIG. 19A
TERMINAL BOARD A2TB1
RACK 7,9,11,13



INTER-RACK CONNECTIONS FOR CHANNEL CARRIER DISTRIBUTION

SYMBOL	CHANNEL DEMULTIPLEX EQUIPMENT RACK			
	7	9	11	13
(E)	(5) FIG. 16A	(8) FIG. 16A	(10) FIG. 16A	(12) FIG. 16A
(F)	(5) FIG. 16A	(10) FIG. 16A	(12) FIG. 16A	NO CONNECTION





FIG. 3E
CHAN DMX

FIG. 5C
GR PLT ALM

FIG. 19B
TERMINAL BOARD A2TB2
RACK 7,9,11,13



INTER-RACK CONNECTIONS FOR ALARM AND POWER DISTRIBUTION

SYMBOL	CHANNEL DEMULTIPLEX EQUIPMENT RACK			
	7	9	11	13
(1)	(5) FIG. 18B	(7) FIG. 19B	(9) FIG. 19B	(11) FIG. 19B
(2)	(5) FIG. 19B	(11) FIG. 19B	(13) FIG. 19B	NO CONNECTION
(3)	(5) FIG. 16C	(8) FIG. 16C	(10) FIG. 16C	(12) FIG. 16C

FIG. 19C
TERMINAL BOARD A2TB3
RACK 7,9,11,13

