Teletype Corporation
Chicago, Illinois, U.S.A.

CHANGES IN ADJUSTMENT BULLETINS

164, Issue 1 - Tape Perforator, Page 5
147, Issue 2 - Nontyping Reperforator, Page 11
148, Issue 2 - Perforator Transmitter, Page 16
165, Issue 3 - Typing Reperforator, Page 2-14
166, Issue 2 - Perforator Transmitter, Page 18
171, Issue 2 - Typing Reperforator, Page 14
178, Issue 1 - Reperforator Transmitter Distributor, Page 25
193, Issue 1 - Reperforator Transmitter Distributor, Page 22
203, Issue 1 - Reperforator Transmitter Distributor, Page 2-15
167, Issue 1 - Tape Perforator, Page 6

Bulletins 178, 193, and 203 - PREPUNCH TAPE TENSION LEVER STUD ADJUSTMENT
Bulletins 147, 148, 165, 166, and 171 - TAPE TENSION LEVER STUD ADJUSTMENT

Change these adjustments to read as follows:

The tape tension lever stud should be centrally located with respect to the feed roll pins. This requirement should be measured as follows:

(a) Take up the feed roll end play towards the star wheel and the tension lever end play towards its adjusting nut. The edge of the lever slot may touch the feed roll pins on the side of the pins nearest the ratchet but there must be clearance on the other side.

(b) Take up the feed roll end play away from the star wheel and the tension lever end play away from the tension adjusting nut. The edge of the lever slot may touch the feed roll pins on the side farthest away from the ratchet but there must be clearance on the other side.

To adjust, add or remove shims between the shoulder on the tape tension lever stud and its mounting bracket.

Bulletins 164 and 167 - TAPE TENSION LEVER STUD ADJUSTMENT

Insert the above adjustment immediately before the TAPE TENSION LEVER SPRING TENSION ADJUSTMENT.

* * *