

.op

13 Februaru 1991

TO° ST-8000Á Partó Lisó Bindeò Holders

RE° Reviseä Partó Lists

Thä encloseä containó á copù oæ #all" partó lisó revisionó É kno+ ♦  
oæ aó oæ thió date@ Á numbeò oæ changeó havá alsí beef ♦  
incorporated@ Wheneveò possible- changeó froí á previúó ♦  
revisioí ará indicateä bù verticalì sidá baró ií thá lefô-haná ♦  
margin@ Alsí encloseä ará revisionó oæ thá HAÌ PARTÓ NUMBERINÇ ♦  
STANDARÄ (87°-99030@ anä thá SÔ-8000Á Partó Lisó Indeø (REV° C)@ ♦  
Pleasá placá thesá aó thá fronò oæ youò binders.

1@ Thá Combineä Partó Listó (PL90°-08005@ no+ includá ali ♦  
hardware- wire- labels- anä shipping materials@ Ne+ parò numbeò ♦  
categorieó havá beef establisheä foò wire- labels- anä shipping ♦  
materials.

2@ Partó Lisó PL90°-0800. ió ne+ anä constituteó á completá ♦  
shipping lisó oæ aí SÔ-8000Á aó iò wili bá shippeä tí thá USAF@ ♦  
Thió lisó #replaces" thá "PL99°-08005ç PACKINÇ LISÓ previouslù ♦  
fileä aó thá enä oæ youò binders@ Remová anä discarä "PL99°-♦  
08005"@

3@ Variúó typographical- parò number- anä quantitù erroró ará ♦  
correcteä ií PL93°-0800¶ (A1)- PL92°-0800µ (A3C)- PL91°-0800µ ♦  
(A5)- PL96°-9000² (A5W2)- PL96°-8000³ (A5W3)- PL96°-8001± ♦  
(A5W11)- PL96°-8001² (A5W12)- PL96°-8001³ (A5W13)- PL96°-8001´ ♦  
(A5T1)- PL96°-8001µ (A5WP1)- PL97°-0800µ (Accessories)- anä ♦  
PL980-0800µ (ST-8000Á Spará Partó Kit).

4@ Additionaì Assemblù Leveló anä twí ne+ assembleó havá beef ♦  
recognizeä anä foldeä inti thá Parò Lisó System@ Thesá are:

- 905-0800´ (A6A@ Cabineò witè ali PCB'ó Installed
- 905-0800µ (A6B@ Completá ST-8000A- #less" accessorieó & Shipping Materials.

Ne+ partó listó foò botè assembleó (A6Á | A6B@ ará enclosed.

Pleasá inserò thá ne+ listó anä #discard" ali previúó lists.

G@ W@ Henry- Jr.

Configuratioí Manager

#####  
#####