

★
NAVSHIPS 92121(A)

INSTRUCTION BOOK

for

RADIO TRANSMITTING SETS

AN/SRT-14, AN/SRT-14A, AN/SRT-15,
AN/SRT-15A, AN/SRT-16 AND AN/SRT-16A

INDEX

FEDERAL TELEPHONE AND RADIO COMPANY

A division of INTERNATIONAL TELEPHONE AND TELEGRAPH CORPORATION

CLIFTON, NEW JERSEY

DEPARTMENT OF THE NAVY

BUREAU OF SHIPS

★
*Contract: NObsr-52021
NObsr-52622*

Approved by BuShips: 26 October 1955

TABLE OF SECTIONS

<i>Section</i>	<i>Title</i>
1	General Description
2	Theory of Operation
3	Installation
4	Operation
5	Operator's Maintenance
6	Preventive Maintenance
7	Corrective Maintenance
8	Parts Lists

INDEX

Note

Illustrations are indexed separately
in the front matter of this book.

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
A		
Abbreviations	1-2	1-3
Adjustments—see individual units		
Alignment		7-118, 7-121
Amplifier stages—		
V-1006 and V-1007		2-73
V-2154		2-14
V-2332 and V-2333		2-26
V-2427 and V-2428		2-29
V-2429		2-29
V-2527, V-2528, and V-2529		2-30
V-2626 and V-2628		2-33
V-2652, V-2653, and V-2654		2-35
V-2802, V-2803, and V-2804		2-38
Antenna Coupler CU-372/SRT—		
bypass switch S-3512		2-118
control-indicator		2-41
description		1-15
electrical adjustments		7-116
function		2-4
grounding cams		2-119
loading switch S-3511		2-119
location		3-7
lubrication		6-25
mechanical adjustments		7-116
position indicator		2-46
trouble location		7-112
Antenna tuning equipment—		
assembly procedure		3-23
connector assemblies	3-5	3-26
control circuit		2-120
critical cable lengths	3-4	3-7
description		1-3
location		3-7
mounting		3-23
system trouble shooting		7-107
test and alignment		7-108
theory of operation		2-116
trial operation		3-36
trouble-shooting chart	7-40	7-107
wiring		3-25
Assembly procedure—		
AN/SRT-14 arrangement "C"		3-8
AN/SRT-15 arrangement "A ₁ "		3-13
AN/SRT-16 arrangement "D"		3-17
Audio amplifier chain		2-67

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Audio amplifiers—		
V-1001 and V-1002A (LLRM)		2-67
V-1002B and V-1004A (LLRM)		2-68
V-1601 and V-1602 (HLRM)		2-88
Audio circuits		2-67, 2-71
Audio input circuit		2-67
Audio oscillator V-1020		2-81
Audio output circuit—		
phaser inverter V-1003B		2-72
power amplifiers V-1006 and V-1007		2-73
push-pull cathode followers V-1005A and V-1005B		2-72
B		
Band information for RFA	2-19	2-101
Bandswitching—		
control		2-114
frequency ranges		2-90, 2-101
Basic features—		
frequency selection		1-1
modes of transmission		1-1
primary power supply		1-1
remote operation		1-1
tuning procedures		1-1
Blocking oscillator V-2202A		2-15
Blowers—		
B-701 and B-702 (mounting)		2-105
B-1306 (RFA)		2-103
motor control		2-124
Booster—see "Radio Modulator-Power Supply OA-685/SRT"		
Buffer-IPA tuning		2-101
Buffer stage—		
input		2-91
keying		2-93
tank circuit		2-91
V-1301 (RFA)		2-91
V-1015A (LLRM)		2-76
C		
Cabinets—see under "Electrical Equipment"		
Carrier on		2-115
Cathode followers—		
V-1002B		2-67
V-1005A and V-1005B		2-72
V-2002 and V-2003		2-7
V-2033 and V-2034		2-8
V-2629		2-33
Chassis—		
removal		5-3
replacement		5-4

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Chassis slides—lubrication		6-24
Check charts	5-3, 6-1	5-5, 6-1
Cleaning and inspection		6-19
Clipper circuits—		
V-1014 (LLRM)		2-68
V-2326A		2-22
Common names	5-1	5-1
Comparison of sets	1-1	1-3
Component characteristics		7-127
Connectors required for antenna tuning equipment	1-1, 3-5	1-3, 3-26
Contact cleaning		7-127
Control circuits—		
antenna tuning		2-114
bandswitching		2-114
carrier on		2-115
facsimile operation		2-115
500-watt operation		2-116
frequency selection		2-114
frequency-shift key operation		2-115
hand-key operation		2-115
IPA and PA tuning		2-114
load adjusting unit tuning		2-114
machine-key operation		2-115
100-watt operation		2-115
phone		2-115
power control		2-111
power supplies		2-112
summary		2-111
Control functions of major units	4-1	4-3
Control-Indicator C-1352/SRT—		
adjustments		7-67, 7-68
ANTENNA COUPLER LOADING ^(AD) switch S-404, control circuit	2-14	2-44
ANTENNA TRANSFER ^(AE) switch S-402, control circuit		2-43
controls		4-8
drive motor control circuit		2-42
lubrication		6-24
position indicator circuit		2-46
SWR indicator circuit		2-46
TRANSFORMER ^(AC) switch S-403, control circuit		2-45
trouble shooting		7-67
Controls—		
functions of major units	4-1	4-3
identification of		4-3
location and normal positions		4-3
Cover CW-341/SRT	1-2, 3-1	1-13
Crystal data		7-129
D		
Description—see Section 1		
Description of sets		1-1
Description of units		1-3

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Disable relay K-1304 (RFA)	2-98
Drive motor control	2-123
Dumping cathode follower (LLRM)	2-79
E		
Electrical adjustments—see under individual units		
Electrical information	1-17
Electrical Equipment Cabinet CY-1571/SRT (transmitter group cabinet)—		
description	1-10
electrical adjustments	7-105
function	2-3, 2-104
mechanical adjustments	7-105
trouble location	7-101
wiring	3-24
Electrical Equipment Cabinet CY-1572/SRT (HLRM cabinet)—		
description	1-13
electrical adjustments	7-105
function	2-4, 2-105
mechanical adjustments	7-105
trouble location	7-105
wiring	3-24
Electrical Equipment Cabinet CY-1573/SRT (HVPS cabinet)—		
description	1-13
electrical adjustments	7-107
function	2-4, 2-105
mechanical adjustments	7-107
trouble location	7-107
wiring	3-24
Electrical equipment rack Z-2901, mounting (unit 14)—		
oscilloscope test receptacles	2-40
test points	2-12	2-40
theory of operation	2-38
see "Radio Frequency Oscillator O-275/SRT"		
wiring	3-24
zero adjust indicating circuit	2-41
Electron tubes—see "Tubes, electron"		
Electronic frequency converter Z-2204, 10-kc step generator (unit 6)—		
see "Radio Frequency Oscillator O-275/SRT"		
Electronic frequency converter Z-2330, 100-kc step generator (unit 8)—		
see "Radio Frequency Oscillator O-275/SRT"		
Electronic frequency converter Z-2426 (unit 9)—see "Radio Frequency Oscillator O-275/SRT"		
Electronic frequency converter Z-2626 (unit 11A)—see "Radio Frequency Oscillator O-275/SRT"		
Electronic frequency converter Z-2651 (unit 11B)—see "Radio Frequency Oscillator O-275/SRT"		
Electronic frequency converter Z-2801 (unit 11C)—see "Radio Frequency Oscillator O-275/SRT"		
Emergency maintenance	5-3
Emission—types of	1-17, 4-1, 4-14
Equipment required but not supplied	1-7	1-21
Equipment supplied	1-6, 3-1	1-20

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
F		
Facsimile—		
operation	2-115
selection	4-14
Filters—		
harmonic, PA	2-97
interference, Z-601 through Z-604	2-105
Frequency bands	2-19	2-101
Frequency converter (unit 5)—see "Radio Frequency Oscillator O-275/SRT"		
Frequencies—		
control of	2-47
final output and control positions	2-15, 4-3	2-47, 4-15
linkages	2-47
sample	2-49
unit 3	2-12
Frequency multiplier Z-2034 (unit 2)—see "Radio Frequency Oscillator O-275/SRT"		
Frequency multiplier Z-2103 (unit 4)—see "Radio Frequency Oscillator O-275/SRT"		
Frequency multiplier Z-2305 (unit 7)—see "Radio Frequency Oscillator O-275/SRT"		
Frequency multiplier Z-2526, 1-mc generator (unit 10)—see "Radio Frequency Oscillator O-275/SRT"		
Frequency selection—		
control circuits	2-114
description	1-1
general	4-1, 4-20
mechanical	2-47
operation	4-15, 4-20
Frequency shift key operation—		
control circuits	2-115
selection	4-14
theory of operation	2-115
Frequency shift oscillator (unit 12)—see "Radio Frequency Oscillator O-275/SRT"		
Front panel test point voltages—weekly record	6-12
FSK operation	4-14
Fuses—		
Adjustments	3-30
500-watt operation	5-9
locations	5-6	5-9
locations of operating spares	5-9
100-watt operation	5-7
operating spares	5-7	5-10
replacement	5-5
symptoms of failure	5-4, 5-5	5-7, 5-8, 5-9
units without fuses	5-10

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
G		
Grounding cams—		
control		2-122
tuning		2-119
H		
Hand-key operation		4-14
Harmonic filters (PA)		2-97
Harmonic generator V-2526		2-30
Heaters—		
cabinet		2-106
HR-701 through HR-704 (in mounting)		2-106
indicator lights		2-40
r-f oscillator		2-12
High level radio modulator (HLRM)—see "Radio Modulator MD-230/SRT"		
HLRM—see "Radio Modulator MD-230/SRT"		
HVPS—see "Power Supply PP-1096/SRT"		
I		
Impedance transformer circuit (LAU)		2-109
Identification of controls and indicators		4-3
Indicators—location		4-3
Initial adjustments		3-28
Input circuits—		
HVPS		2-61
LLRM		2-74
LVPS		2-51
Installation—		
assembly procedure		3-8
equipment arrangement		3-5
kits—see tables 1-2, 1-6		
materials	3-3	1-17, 3-4
Interference filters Z-601 through Z-604		2-105
Interlock circuit and -24-volt d-c supply (LVPS)		2-54
Interpolation oscillator Z-2053 (unit 3)—see "Radio Frequency Oscillator O-275/SRT"		
IPA—		
current meter M-1304		2-103
input		2-93
meter selector switch (G) S-1386	2-21	2-103
tank circuit		2-93
tuning		2-114
V-1302		2-93
Isolating amplifier V-2201		2-15
K		
Keying—high speed or tape		4-15
Keying circuit (LLRM)—		
audio oscillator V-1020		2-81

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Keying circuit (Cont'd)—		
buffer V-1015A	2-76
dumping cathode follower	2-79
functions of keying circuit outputs	2-16	2-75
keyer V-1019	2-80
keying control	2-76
keying multivibrator outputs	2-78
limiter V-1018	2-79
multivibrator V-1017	2-76
KEYING RATE switch (S) S-1109 (LLRM)	2-17	2-79
Keying voltages (LLRM)—monthly record	6-8	6-12
L		
Limiters—		
V-1013B	2-70
V-1018	2-79
LLRM—see "Radio Modulator MD-229/SRT"		
Localization—theory of	7-2
Location of equipment—		
Antenna Coupler CU-372/SRT	3-7
antenna tuning equipment	3-7
clearance requirements	3-5
Radio Frequency Tuner TN-229/SRT	3-7
remote radiophone unit	3-8
transmitter bay	3-5
variations in transmitter bay arrangements	3-5
Low level radio modulator—see "Radio Modulator MD-229/SRT"		
Low voltage power supply—see "Power Supply PP-1094/SRT"		
Lubrication—		
actuator motor	6-25
annual	6-28
ball bearings	6-32
bandswitch mechanism	6-22
base mount	6-24
biennial	6-28
chains	6-32
chassis slides	6-24
control-indicator	6-24
dry cleaning solvent (for removal of grease, oil and dirt)	6-28
frames and base mounts	6-21
gears and racks	6-24
general procedure	6-21
greases	6-12	6-28, 6-29
intervals	6-25
IPA dial assembly	6-22
jacks	6-24
LLRM	6-24
major overhaul	6-28
motors	6-32
oils	6-13	6-28, 6-29
PA dial assembly	6-22
PA tuning mechanism	6-22
periods	6-25

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Lubrication (Cont'd)—		
quarterly		6-26
RFA		6-21
RFO		6-22
r-f tuner		6-24
semiannual		6-26
three year		6-28
tools		6-28
typical RFO points		6-22
wafer switches and detents		6-32
LVPS—see "Power Supply PP-1094/SRT"		
M		
Machine-key operation		2-115, 4-14
Magnetic clutch control		2-123
Main test cable assembly		3-25
Maintenance—		
check charts	5-3, 6-4	5-5, 6-4
emergency		5-3
procedures		6-19
see Sections 5, 6, 7		
special—		
base mount motors B-701 and B-702		6-34
chains		6-32
gears and racks		6-31
jacks and plugs		6-31
motors		6-32
relays		6-30
RFA blower motor B-1306		6-34
r-f tuner and coupler motors		6-34
Major control functions	4-1	4-3
Major units—		
description	1-1	1-3, 2-1
trouble shooting and repair		7-8
Mechanical linkages		2-47
Mechanical selection of a frequency		2-47
Medium voltage power supply—see "Power Supply PP-1095/SRT"		
Metering circuits (RFA)—		
IPA current meter M-1304		2-103
PA current meter M-1303		2-103
voltmeter M-1301		2-103
Meters—typical readings	3-8	3-33
Mixers—		
V-2151		2-14
V-2152		2-14
V-2153		2-12
V-2203		2-16
V-2206		2-20
V-2207		2-20
V-2230		2-24
V-2327		2-22
V-2331		2-24

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Mixers (Cont'd)—		
V-2426	2-27
V-2626	2-33
V-2651	2-35
V-2801	2-38
Modes of transmission	1-1, 4-1
Modulation percentage check	4-15, 4-20, 7-71
Modulator—see "Radio Modulator"		
Monitoring signals	4-20
Motors—general maintenance	6-34
Mounting—		
antenna tuning equipment	3-23
Transmitter Coupler CU-402/SRT	3-23
Mounting MT-1423/SRT (mounting)—		
adjustments	7-101
blowers	2-105
description	1-11
function	2-4
heaters	2-106
lubricating	6-24
theory	2-105
trouble location	7-99
N		
Nomenclatures—		
major units	1-1, 1-2	1-3
standard test sets	1-15
subunits of RFO	1-9
test cables	1-5	1-17
O		
Operation—see Section 4		
Operator's maintenance—see Section 5		
Oscillators—		
V-2001	2-7
V-2051	2-9
V-2128	2-12
V-2329	2-22
Oscilloscope test receptacles	2-13	2-40, 2-41
Output circuit	2-12
P		
PA—		
current meter M-1303	2-103
harmonic filter	2-97
input	2-93
METER SELECTOR switch (H) S-1387	2-22	2-103
plate circuit	2-95
screen circuit	2-94
tube V-1304	2-93
Phase inverter V-1003B (LLRM)	2-72
Phone operation	4-15, 4-20

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Position indicator circuit	2-46
Power control	4-1
Power supplies—		
control circuits	2-112
HVPS	2-114
LLRM	2-114
LVPS	2-113
MVPS	2-113
Power Supply PP-1094/SRT (low voltage power supply, LVPS)—		
adjustments	7-95
controls	4-9
description	1-10
function	2-3
indicators	4-10
input circuits	2-51
interlock circuit and -24-volt d-c supply	2-54
stop-start circuit	2-53
theory of operation	2-51
+250-volt d-c unregulated supply	2-56
+300-volt d-c supply	2-56
-220-volt d-c supply	2-56
trouble shooting	7-36	7-95, 7-96
Power Supply PP-1095/SRT (medium voltage power supply, MVPS)—		
adjustments	7-97, 7-99
controls	4-10
description	1-10
+500-volt d-c supply	2-58
indications of failure and probable faults	7-37	7-97
+1,050/+1,300-volt d-c supply	2-59
300-volt switch relay	2-59
theory of operation	2-58
trouble location	7-97
voltages measured at RFA voltmeter	7-38	7-97
Power Supply PP-1096/SRT (high voltage power supply, HVPS)—		
adjustments	7-99
controls	4-11
description	1-13
functions	2-3
indications of failure and probable faults	7-39	7-99
indicators	4-12
input circuit	2-61
trouble location	7-99
+2,400/+3,000-volt supply	2-65
Preliminary control settings	5-2	5-3
Pressurization	3-36, 5-14, 6-36
Primary checks	6-1	6-1
Primary power	1-1
R		
Radio Frequency Amplifier AM-1008/SRT (RFA)—		
antenna switching relay K-1306	2-100
bandswitching	2-101
blower motor B-1306	2-103

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Radio Frequency Amplifier AM-1008/SRT (Cont'd)-		
buffer input		2-91
buffer IPA tuning		2-101
buffer keying		2-93
buffer tank circuit		2-91
buffer V-1301		2-91
control circuits		2-97
control functions	4-1	4-3
description		1-7
electrical adjustments		7-82
500-watt disable line		2-98
500-watt operate relay K-1304		2-98
function		2-3
identification of controls		4-3
individual functions		4-3, 4-4, 4-5
IPA V-1302		2-93
lubrication		6-21
mechanical adjustments		7-89
metering circuits		2-103
meter readings-		
100-watt operation	6-2	6-3
500-watt operation	6-3	6-3
weekly record	6-5	6-10
PA tuning		2-101
PA V-1304		2-93
r-f line filter Z-1301		2-103
theory of operation		2-90
trouble shooting		7-81
typical meter readings	7-35	7-81
Radio Frequency Oscillator O-275/SRT (RFO)-		
circuit analysis		2-4
control indicator-see "Control-Indicator C-1352/SRT"		
control functions		4-3
control of frequencies		2-47
control panel removed		6-23
critical adjustments	3-9	3-33
description		1-8
final output frequencies	2-15	2-47
5-mc step switch S-2426	2-4	2-29
front panel control knobs	7-4	7-13
function		2-1
identification of controls		4-6
indicators		4-7, 4-8
lubrication		6-22
manual operation		2-49
mechanical linkages		2-47
mechanical selection of a frequency		2-47
metering socket voltages, weekly record	6-6	6-10
oscilloscope test receptacles		4-20
output to RFA	2-7	2-32
preliminary checks	7-2	7-10
production of a sample frequency		2-49
subunit functioning		2-49
subunit test cable (power)	1-5	1-17
test jack voltages, monthly record	6-9	6-14

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Radio Frequency Oscillator O-275/SRT (Cont'd)-		
test point socket E-2919	7-3	7-11
theory of operation		2-4
trouble shooting		7-8
unit adjustments		6-12
unit 1 (crystal oscillator Z-2001)-		
adjustments	3-9	3-33, 6-12, 7-18
cathode followers V-2002 and V-2003		2-7
crystal oscillator V-2001		2-7
electrical adjustments		7-18
mechanical adjustments		7-18
r-f voltage at test points	7-5	7-15
theory of operation		2-7
trouble shooting		7-15
unit 2 (frequency multiplier Z-2034)-		
adjustments		7-20
cathode followers V-2033 and V-2034		2-8
frequency doubler V-2032		2-8
frequency quintupler V-2031		2-8
r-f voltage at test points	7-6	7-15
trouble shooting		
unit 3 (interpolation oscillator Z-2053)-		
adjustments	3-9	3-33, 6-13, 7-21, 7-25
alignment		7-23
frequency selection		2-10
heater circuit		2-12
lubrication		6-24
1-kc steps		2-10
10-cycle steps		2-10
100-cycle steps		2-10
oscillator V-2051		2-9
output circuit		2-12
preliminary checks with external oscilloscope	7-2	7-10
trouble shooting	7-8, 7-9	7-21, 7-25
unit 4 (frequency multiplier Z-2103)-		
adjustments		7-27, 7-28
frequency doubler V-2102		2-9
frequency quadrupler V-2101		2-8
unit 5 (frequency converter)-		
1.1-mc mixer V-2151		2-14
1.19- to 1.2-mc mixer V-2152		2-14
9.19- to 9.2-mc mixer V-2153 and amplifier V-2154		2-14
trouble shooting	7-10	7-28
unit 6 (electronic frequency converter Z-2204, 10-kc step gener- ator)-		
adjustments	3-9, 7-12, 7-13	3-33, 6-15, 7-31, 7-33, 7-34
amplifiers V-2208 and V-2209		2-20
blocking oscillator V-2202A and shaper V-2202B		2-15
isolating amplifier V-2201		2-15
1.21- to 1.3-mc mixer V-2206		2-20

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Radio Frequency Oscillator O-275/SRT (Cont'd)—		
r-f voltage at test points	7-11	7-31
step oscillator V-2205, mixer V-2203 and reactance tube V-2204		2-16
10.4- to 10.5-mc mixer V-2207		2-20
10-kc step oscillator check	6-10	6-17
10-kc step switch S-2201	2-1	2-20
trouble shooting		7-30
unit 7 (frequency multiplier Z-2305)—		
frequency quintupler V-2301 and amplifier V-2302		2-20
frequency tripler V-2303 and amplifier V-2304		2-21
trouble shooting		7-38
unit 8 (electronic frequency converter Z-2330, 100-kc step gener- ator)—		
adjustments	3-9, 7-15, 7-16, 7-17	3-34, 7-41, 7-43, 7-44
amplifiers V-2332 and V-2333		2-26
cathode follower V-2334		2-24
clipper V-2326A and shaper V-2326B		2-22
lubrication		6-22
100-kc adjustment		6-17
100-kc step oscillator check	6-11	6-17
100-kc step switch S-2326	2-2	2-24
oscillator V-2329, mixer V-2327, and reactance tube V-2328		2-22
removal procedure		6-23
replacement procedure		6-23
16.6- to 17.5-mc mixer V-2230		2-24
27- to 28-mc mixer V-2331		2-24
unit 9 (electronic frequency converter Z-2426)—		
adjustments	7-20, 7-21	7-45, 7-46, 7-47
amplifier V-2429		2-29
amplifiers V-2427 and V-2428		2-29
5-mc step switch S-2426	2-4	2-30
lubrication		6-22
mixer outputs	2-3	2-26
mixer V-2426		2-27
100-kc step switch S-2427		2-30
trouble shooting		7-45
unit 10 (frequency multiplier Z-2526, 1-mc step generator)—		
amplifiers V-2527, V-2528, and V-2529		2-30
harmonic generator V-2526		2-30
lubrication		6-22
1-mc step switch S-2526	2-6	2-32
trouble shooting	7-22, 7-23	7-49, 7-51
unit 11A (electron frequency converter Z-2626)—		
amplifiers V-2626 and V-2628		2-33
cathode follower V-2629		2-33
mixer V-2626		2-33
trouble shooting	7-24	7-52
unit 11B (electronic frequency converter Z-2651)—		
amplifiers V-2652, V-2653, and V-2654		2-35

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Radio Frequency Oscillator O-275/SRT (Cont'd)—		
lubrication		6-24
mixer V-2651		2-35
1-kc step switch S-2651	2-8	2-35
100-kc step switch S-2652	2-9	2-37, 2-38
trouble shooting	7-25, 7-26, 7-27	7-53, 7-56, 7-57
unit 11C (electronic frequency converter Z-2801)—		
amplifiers V-2802, V-2803, and V-2804		2-38
mixer V-2801		2-38
1-mc step switch S-2801	2-10	2-38
100-kc step switch S-2802	2-11	2-40
trouble shooting	7-28, 7-29, 7-30	7-56, 7-57, 7-60, 7-61
unit 12 (radio frequency oscillator Z-2127, frequency shift oscil- lator)		
adjustments		7-63
cathode follower V-2126		2-13
control tube V-2127		2-13
miscellaneous		2-14
oscillator V-2128		2-12
trouble shooting		7-63
unit 14 (electrical equipment rack Z-2901, mounting)—		
adjustments		7-12, 7-13
heater indicator lights		2-40
oscilloscope test receptacles		2-40
test points	2-12	2-40
trouble shooting		7-12
zero adjust indicating circuit		2-41
Radio Frequency Tuner TN-229/SRT (r-f tuner)—		
description		1-14
electrical adjustments		7-122
function		2-4
impedance transformer		2-117
location		3-7
lubrication		6-24
main tuning coil		2-116
mechanical adjustments		7-123
pressurizing procedure		6-36
purging procedure		7-126
removal and repair		7-123
trouble shooting	7-41	7-121, 7-122
tuning		2-116
Radio Modulator-Power Supply OA-685/SRT (booster)—		
BOOSTER EMERGENCY SWITCH Ⓢ		4-12
control functions	4-1	4-3
description		1-12
mounting		3-24
see "Radio Modulator MD-230/SRT (HLRM)," "Power Supply PP-1096/SRT (HVPS)," "Electrical Equipment Cabinet CY- 1572/SRT (HLRM Cabinet)," "Electrical Equipment Cabinet CY-1573/SRT (HVPS cabinet)"		
wiring		3-24

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Radio Modulator MD-229/SRT (low level radio modulator, LLRM)—		
AGC rectifier V-1013A		2-67
ATU bypass transfer circuit		2-86
audio amplifier chain		2-67
audio amplifiers V-1001 and V-1002A		2-67
audio amplifiers V-1004A and V-1002B		2-68
audio input circuit		2-67
audio output circuit		2-71
cathode follower V-1002B		2-67
clipper V-1014		2-68
control functions	4-1	4-3
description		1-8
electrical adjustments		7-73
function		2-3
identification of controls		4-5
indications of failure and probable faults in the audio circuits	7-31	7-72
indications of failure and probable faults in the keying circuits	7-32	7-73
indications of failure and probable faults in the power supplies	7-33	7-73
keying circuit	2-16	2-74, 2-75
LOCAL-REM. switch (X) S-1106		2-83
lubrication		6-24
sidetone amplifier V-1004B		2-71
squelch circuit		2-69
squelch multivibrator V-1008		2-69
theory of operation		2-65
trouble shooting	7-31	7-68, 7-72
-12-volt power supply		7-77
+250-volt regulated power supply		2-83
Radio Modulator MD-230/SRT (high level radio modulator, HLRM)—		
audio amplifiers V-1601 and V-1602		2-88
description		1-12
electrical adjustment		7-79
-50-volt bias supply		2-89
function		2-3
indications of failure and probable faults	7-34	7-79
indicators		4-11
mechanical adjustments		7-79
regulated +360-volt d-c supply		2-89
theory of operation		2-87
trouble shooting		7-77
Rectifiers—see "Power supplies"		
Reference data		1-17
Relays—maintenance		7-127
Remote operation—		
controls		4-19
description		1-14
frequency selection		4-19
preliminary settings		4-19
tuning		4-19
Remote radiophone unit		1-14, 2-3, 2-87, 3-8, 3-25

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
RFA—see "Radio Frequency Amplifier AM-1008/SRT"		
RFO—see "Radio Frequency Oscillator O-275/SRT"		
RFO units 1 through 12 and 14—see table 1-3		
Repair and adjustments—see individual units		
Routine checks and chart	5-3	5-5
Routine maintenance and check chart	6-4	6-3
S		
Sample frequency		2-49
Selecting a frequency		4-15
Selecting a service—		
facsimile operation		4-14
FSK operation		4-14
hand-key operation		4-14
high-speed or tape keying		4-15
machine-key operation		4-14
phone operation		4-15
Shaper V-2202B		2-15
Shaper V-2326B		2-22
Shipping data	1-8, 3-2	1-21, 3-2
Shutdown procedure		5-14
Sidetone amplifier V-1004B		2-71
Spare parts	8-5	1-17, 8-273
Squelch circuit—		
multivibrator V-1008		2-69
limiter V-1013B		2-70
rectifier CR-1002		2-70
Step switches—		
S-2201 (10 kc), unit 6	2-1	2-21
S-2326 (100 kc), unit 8	2-22	2-24
S-2426 (5 mc), unit 9	2-4	2-29
S-2427 (100 kc), unit 9	2-5	2-30
S-2526 (1 mc), unit 10	2-6	2-32
S-2651 (1 mc), unit 11B	2-8	2-35
S-2652 (100 kc), unit 11B	2-9	2-37
S-2801 (1 mc), unit 11C	2-10	2-38
S-2802 (100 kc), unit 11C	2-11	2-40
Stop-start circuit		2-53
Subunits of RFO	1-3	1-9
SWR indicator circuit		2-46
SWR monitor circuit		2-107
T		
Tape keying		4-15
Test cables	1-5	1-16
Test equipment—		
required		7-2
special		1-16
standard	1-4	1-15
Theory of localization		7-2
Theory of operation—see Section 2		

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Tools—special		1-16
Transformer windings	7-43	7-129, 7-131
Transmitter bay—		
assembly procedure		3-8
control circuits		2-110
location and arrangements		3-5
sequence of operation		2-110
summary		2-111
trial operation		3-30
trouble shooting		7-2
wiring		3-24
Transmitter Coupler CU-402/SRT (load adjusting unit, LAU)— adjustments—		
electrical		7-109
mechanical		7-112
controls		4-11
description		1-11
function		2-3
impedance transformer circuit		2-109
mounting		3-23
standing wave ratio monitor circuit		2-107
theory of operation		2-107
trouble location		7-108
wiring		3-25
Transmitter Group OA-684/SRT (transmitter group)—		
description		1-3
drawer removal procedure		5-3
power on and off		4-12
see "Electrical Equipment Cabinet CY-1571/SRT," "Radio Fre- quency Amplifier AM-1008/SRT," "Radio Modulator MD- 229/SRT," "Radio Frequency Oscillator O-275/SRT," "Power Supply PP-1094/SRT," "Power Supply PP-1095/SRT," "Transmitter Coupler CU-402/SRT"		
Trouble shooting—		
Antenna Coupler CU-372/SRT		7-112
antenna tuning equipment		7-107
Cabinet, CY-1571/SRT		7-101
Cabinet, CY-1572/SRT		7-105
Cabinet, CY-1573/SRT		7-107
control-indicator		7-67
HLRM	7-34	7-77
HVPS	7-39	7-99
LLRM	7-31	7-68
LVPS	7-36	7-95
MVPS	7-38	7-97
Mounting MT-1423/SRT		7-99
RFA	7-35	7-81
RFO	7-2	7-8
	through	
	7-30	
Radio Frequency Tuner TN-229/SRT	7-41	7-121
see also individual units		

INDEX (Cont'd)

<i>Subject</i>	<i>Table Number</i>	<i>Text Page</i>
Trouble Shooting (Cont'd)—		
system	7-1	7-3
transmitter bay	7-2
Transmitter Coupler CU-402/SRT	7-108
Tubes, electron—		
characteristics	7-42	7-128
checking	3-30
complement	1-9	1-22
critical circuit adjustments	3-9, 5-9	3-33, 5-13
location	5-8	5-11
record of tube changes	6-15	6-35
removal and replacement, special—		
V-1301	5-13
V-1302	5-13
V-1304	5-10
units without tubes	5-13
Tuning—		
bands	4-1
capacitors	4-20
operations	4-16
to a calibrated frequency	4-17
to an uncalibrated frequency	4-16
variances	4-18
Turning power on and off	4-12, 4-20
U		
Unpacking procedures	3-1
Units 1 through 14	1-3	1-9
Units without controls	4-3
Units without tubes	5-13
V		
Vacuum tubes—see "Tubes, electron"		
Voltage and resistance charts—see "Index of Illustrations"		
W		
Winding data	7-43	7-131
Wiring the equipment—		
antenna tuning equipment	3-25
mounting	3-24
radio modulator-power supply	3-24
remote radiophone unit	3-25
transmitter bay	3-24
transmitter coupler	3-25
transmitter group cabinets	3-24