

INSTRUCTION MANUAL FOR TELETYPE MODEL 19

PAGE PRINTER SET

(Arranged for Multi-Voltage, Multi-Frequency Operation)

CONTENTS

General

- Specification 5475S, Issue 1.....General Description
Specification 5288S, Issue 1.....Lubrication Supplies and
Directions for Use
Correction Sheet 700EE.....Supplement to all Parts Catalogs

Model 15 Page Printer and Perforator Transmitter

- Bulletin 144, Issue 2.....Description - Printer
Bulletin 138, Issue 5.....Adjustments - Printer
Correction Sheets EE474, 508, 524, 534, 556,
559, 562, 580, 583, 594, 605, 607, 617, 631,
656, 681, 689, 695, 720, 721, 733, 737, 565
Bulletin 1094, Issue 2.....Parts Catalog - Printer
Correction Sheets EP442, 485, 514, 516, 527,
530, 601, 618, 621, 622, 650, 696, 707, 738
Bulletin 166, Issue 2.....Description and Adjustments
Perforator Transmitter
Correction Sheets EE557, 597, 628, 699, 715, 732
Bulletin 1090, Issue 2.....Parts Catalog
Perforator Transmitter
Correction Sheets EE493, 525, 527, 736, 482
Drawing 1620WD.....Wiring Diagram
Drawing 2143WD.....Wiring Diagram
Drawing 2386WD.....Wiring Diagram

Line Relay

- Bulletin 120, Issue 7.....Description, Adjustments
and Wiring Diagram
Bulletin 1044, Issue 4.....Parts Catalog

Model 14 Transmitter Distributor

- Bulletin 141, Issue 3.....Description and Adjustments

Contents

Correction Sheets EE464, 475, 501,
510, 543, 582, 591, 592, 607

Bulletin 1109, Issue 1.....Parts Catalog
Correction Sheets EE483, 50 , 515, 516, 622, 646, 650

Drawing 2084WD.....Wiring Diagram

Metal Table

Bulletin 1077, Issue 3.....Parts Catalog
Correction Sheet EE484.

Drawing 2161WD.....Schematic).....Model 19 Table
Wiring Diagram

Drawing 2162WD.....Actual)

Rectifiers

Specification 5269S, Issue 4 (REC13, 60 Cycle).....Description, Adjustments
Parts Catalog and
Wiring Diagram

Specification 5367S, Issue 4
(REC30, Multi-Voltage, Multi-Frequency)

Specification 5472S, Issue 1.....Instructions for Securing
Rectifier to Table