TYPICAL SSB RECEIVER

VARIABLE ATTEN-UATOR NETWORK

HF AMP V1

MIXER V2

MF AMP V4

F1 LATTICE FILTER

MF BAL. MIXER V5

V6

VARIABLE ATTEN-UATOR SIDE BAND LEVEL CONTROL

LF AMP V9

LF AMP V10

LF AMP VII

LF BAL DEMOD V12

TO AUDIO AMPS

HF OSC TUNING

HF OSC V3

HTR SUPPLY

OSC V7

V8

AVC 3

AVC 2

MANUAL NG R69 Control

AVC RECT. V17

BIAS SUPPLY

AMP V14

AMP V15

CARRIER FILTER 4 SECT

AMP V16

LF OSC

S5

CARRIER

EXALTED CARRIER AMPL V18

OSC OUT AMP V19

V19

SWS

AFC BAL MOD AV25

AFC BAL MOD A V26

AFC BAL MOD B V27

AFC BAL MOD B V28

MANUAL RESET

INDICATOR

M1 WINDINGS

CARRIER BRANCH AMP V23

CARRIER BRANCH AMP V24

OSC BRANCH AMP V21

OSC. BRANCH AMP V22

LF OSC V20

AFC ELECT. RESET spring loaded in the up or down position.

PHASE NET N3