


TELETYPE equipment for





Today's increasingly complex business and industrial world demands fast and accurate dissemination of information.

An extremely economical way to obtain instant, accurate printed data communications is through the use of Teletype® 5-level data terminals.

Teletype offers two lines of 5-level equipment: the heavy-duty Teletype 28 data terminal designed for continuous operation, and Teletype 32 data terminal for less demanding applications.

With either terminal you have full use of a 5-level code containing 32 combinations. A shift mechanism extends the number of combinations available to 62; of these, 26 are assigned to letters of the alphabet, with the remainder for numerals, punctuation and machine control functions.

This equipment operates at 10 characters per second (100 words per minute), or less where required. And can be equipped to send and receive messages simultaneously.

Both terminals deliver the flexibility and economy required to simplify data exchange problems. Provide permanent and accurate records instantly. As a message is transmitted it is printed in identical form on receiving terminals. Check it out. You'll find that on a price/performance basis—Teletype 5-level equipment is truly in a class by itself.


Black perforated tape on cover reads: HEAVY DUTY 5-LEVEL DATA COMMUNICATIONS


automatic send-receive sets

Teletype 28 and 32 Automatic Send-Receive (ASR) data terminals provide fast, accurate data transmission automatically using 5-level punched paper tape.

- flexibility of tape Operators can punch messages off-line on tape for later errorless transmission. Messages can be collected from many sources at different times and combined into a single tape for economical on-line transmission at maximum speed. Basic data can be punched in tape, stored, used when needed, or even combined with variable data to save retyping.
 - keyboards Keyboards are designed for a light, uniform touch, and use a lettersfigures shift combination for data preparation. Letters appearing on lower keytops are actuated by first depressing the LTRS key. To generate characters on the upper key portion, the FIGS key is first depressed. Control function keys make up the rest of the keyboard.
- mode control selection On Model 28 equipment, a mode control selector provides three different modes of operation. 1. You can transmit messages while simultaneously punching a tape. 2. You can punch tape off-line, freeing the page printer to receive separate incoming messages. 3. Or you can punch a tape off-line while monitoring transmissions from the terminal's tape reader.

On Model 32 equipment, you can transmit data directly from keyboard, with or without punching tape. In local mode, messages can be prepared on tape, along with page copy to verify accuracy. Tape reader and punch can be used in local mode to duplicate tape. Data can be received in page copy form with or without perforating tape. Data can be sent on-line automatically using tape.





Model 32 automatic send-receive set: Paper tape punch has four operating buttons. "ON" and "OFF" buttons to start and stop operation. A "BACKSPACE" button used to delete errors and a "RELEASE" for easy tape insertion. A "V" shaped tear-off edge makes it easy to identify beginning and end of the tape. Paper tape reader has 3-way operating switch for START, STOP, and FREE-WHEELING operation. Automatically shuts off when end of tape is reached. Model 28 automatic send-receive set: Paper tape punch and reader can be used for chadless or fully-perforated 5-level tape operation. A punch is available which will print characters between tape feed holes, six spaces behind the respective punched characters.



All features on Teletype 28 and 32 keyboard sendreceive (KSR) data terminals are the same as on the ASR terminals, except for the paper tape punch and reader capability.

These terminals can transmit and record messages by manual operation of the keyboards, using an 81/2 in. friction-feed platen capable of handling single or multiply paper in roll diameters of 5 in, maximum.

Both 5-level data terminals are also available without keyboards for receive-only (RO) applications to record messages sent from other Teletype terminals. In addition, Teletype 28 KSR and RO terminals can be ordered in space-saving table- or wall-mounted models.

stunt and function box control

The Teletype 28 terminals have a stunt box and Teletype 32 terminals have a function box to control such non-printing functions as automatic carriage return, and activating remote apparatus (including paper tape punches and readers, business machine and meter devices).

Basically, the stunt box initiates internal mechanical functions and electrically controls internal and external functions.

model 32 international keyboard


This optional keyboard is compatible with most communications systems throughout the world. Incorporates CCITT (Consultative Committee on International Telephone and Telegraph) recommended features and requirements. 4-row keyboard uses letters-figures shift combination. but numbers are separated from character keys on top row of keys.


model 32 (3-row) keyboard


Uses letters-shift combination. LTRS key is depressed to transmit characters on lower part of keytop, FIGS key is depressed to transmit characters on upper portion of keytop. Machine control keys are separated (right-hand side) from character keys.

model 28 (3-row) keyboard

Operation of the model 28 keyboard is similar to the model 32 (3-row) keyboard. Control function keys however are positioned above the 3 rows of character kevs.









optional features

automatic "answer-back"

Model 28 and 32 terminals are available with an answer-back mechanism for automatic unattended operation. Remote stations can be called in at any time and data transmitted without an operator being present.

TELETYPE 28 AND 32 DATA TERMINALS . . . can be equipped with low-paper alarm. The model 28 can be equipped with horizontal and vertical tabulators.

A sprocket feed platen is available with model 28 and model 32 equipment that enables typing of business forms on-line. Providing multiple copies both locally and at remote stations.

Model 28 wall mounted unit


more information

Teletype Corporation continually encourages the correspondence of companies and individuals interested in the science of data communications. For more information about:

LEASED SERVICES featuring Teletype 5-level data communications terminals, consult your local telephone or telegraph company.

PURCHASING or general information about this or any Teletype equipment, contact our Sales Organization at one of the locations listed on the back cover.

When ordering input-output terminals for your DATA PROCESSING SYSTEM, be sure to specify Teletype equipment—your vital communications link.





technical information

model 28

speed

Characters Per Second	6	6.6	7.5	10.0
Words Per Minute	60	66	75	100
Unit Codes		Ba	uds	
7.0	42.0	46.2	52.5	70.0
7.42	44.5	49.0	55.7	74.2
7.5	45.0	49.8	56.3	75.0

code

5-level with start-stop signals in 7.0, 7.42, and 7.5 unit transmission pattern

tape

5-level, chadless or fully perforated, oiled paper tape; 11/16 in. wide

printer

Standard form widths 3% in. to 9½ in.; friction or sprocket feed

51 alphanumerics, plus special characters, printed uppercase at 5, 6, 8, 10, or 12 per inch

Line feeds at 2, 3, 4, 6, or 8 lines per inch

Form positioning for standard form lengths 2 to 15 inches

Horizontal and vertical tabulation

keyboard

3-row, 32 key LETTERS-FIGURES shift

power requirements

115 V AC @ 50 or 60 Hz or 115 V DC

maintenance interval

Once every six months or after 1500 operating hours, whichever occurs first

temperature and humidity

40 to 110° F.

95% humidity maximum

dimensions and weight

Unit	Height	Width	Depth	Approx Weight
Floor M	odel		1100	
RO	39 in.	20½ in.	18½ in.	115 lbs.
KSR	39 in.	20½ in.	24 in.	130 lbs.
ASR	39 in.	36 in.	24 in.	260 lbs.
Table M	odel			
RO	16 in.	201/2 in.	21 in.	75 lbs.
KSR	16 in.	201/3 in.	24 in.	90 lbs.
Wall Mo	del			All second
RO	30 in.	16½ in.	11% in.	105 lbs.
KSR	30 in.	16½ in.	14½ in.	110 lbs.

model 32

spead

Characters Per Second	6	6.6	7.5	10
Words Per Minute	60	66	75	100
Bauds	45.0	49.5	56.3	75.0

code

5-level start-stop signals with 7.5 unit transmission pattern

tape

5-level fully perforated 11/16 in. wide

printer

Friction or sprocket feed platen for 8½ in. single or multiple-ply paper

10 characters per inch

adjusted for 72 character line

vertical spacing 6 lines per inch

single or double row spacing

keyboard

3-row or 4-row 5-level

power requirements

115 V AC @ 50 or 60 Hz, or 115 V DC, single phase synchronous motor

maintenance interval

Once every six months or after 500 operating hours, whichever occurs first

temperature and humidity

40° to 110° F. 95% humidity maximum

dimensions and weight

Unit	Height	Width	Depth	Approx Weight
RO	32% in.	18% in.	18½ in.	52 lbs.
KSR	32% in.	18% in.	18½ in.	54 lbs.
ASR	32% in.	22 in.	18½ in.	56 lbs.



For further information on any Teletype Corporation product lines, or for the location of your nearest sales or product service representative, please contact:

Sales headquarters— 5555 W. Touhy Ave. Skokie, Illinois 60076 Product Service headquarters— 9930 Derby Lane Westchester, Illinois 60153

or call TERMINAL CENTRAL-(312) 982-2500

TELETYPE CORPORATION

the computercations people

GENERAL OFFICES: 5555 Touhy Avenue, Skokie, Illinois 60076 Telephone: (312) 982-2000-TWX: 910-223-3611 and TELEX: 25-4051 (both have 24 hour automatic answering service)

25/3210M473