

Technical Order No. 31R2-4-1024-1

ST-8000A FSK MODEM

OPERATOR'S MANUAL

Copyright 1991 by HAL Communications Corp., Urbana, Illinois.
Printed in the United States of America. Contents of this
publication may not be reproduced in any form without the written
permission of the copyright owner.

870-08005
April 16, 1991 Printing

ST-8000A FSK MODEM

OPERATOR'S MANUAL

TABLE OF CONTENTS:

CHAPTER 1	INTRODUCTION
1-1		
1.1	PURPOSE
1-1		
1.2	GENERAL DESCRIPTION
1-1		
1.3	SPECIFICATIONS
1-2		
1.3.1	Demodulator
1-2		
1.3.2	Modulator
1-3		
1.3.3	Modem Control
1-4		
1.3.4	Front Panel
1-4		
1.3.5	Remote Control
1-5		
1.3.6	Rear Panel Connections
1-6		
1.3.7	Other Rear Panel Devices
1-7		
1.3.8	Physical Data
1-7		
1.3.9	Compatibility
1-7		

CHAPTER 2 INSTALLATION

2.1	GENERAL
2-1		
2.2	UNPACKING AND INSPECTION
2-1		
2.2.1	Unpacking
2-1		
2.2.2	St-8000A Accessories
2-3		
2.3	POWER REQUIREMENTS

2-4	2.3.1	Voltage and Frequency
2-4	2.3.2	AC Power Cord
2-6	2.3.2.1	United States AC Power Connection
2-6	2.3.2.2	Host Nation AC Power Connection
2-6	2.3.2.3	Military AC Power Connection
2-7		
2.4	RACK MOUNTING	
2-8		
2.5	USER-SET OPTION SWITCHES AND JUMPERS	
2-9		
2-11	2.5.1	Demodulator Input Impedance
2-12	2.5.2	Automatic Mark Hold (AMH) Settings
2-13	2.5.3	Demodulator LOS / Carrier Detect (CD)
2-13	2.5.4	Modulator Tone Auto-Mute Setting
2-14	2.5.5	Remote Control Data Rate
2-15	2.5.6	Remote Control Address
2-16	2.5.7	Auto-Mute Delay
2-18	2.5.8	RS-232 / MIL-188 Data Format
2-19	2.5.9	Remote Control Terminations
2-19	2.5.10	Log Option Settings

ST-8000A OPERATOR'S MANUAL

TABLE OF CONTENTS (Continued) :

2.6 CABLE CONNECTIONS	2-21
2.6.1 Audio I/O Connections	2-21
2.6.1.1 Radio System Connections	2-22
2.6.1.1.1 Modulator FSK Audio Output ..	2-22
2.6.1.1.2 Keyline Connections	2-22
2.6.1.1.3 Demodulator FSK Audio Input	2-22
2.6.1.2 4-Wire Line Connections	2-25
2.6.1.3 2-Wire Line Connections	2-28
2.6.2 Data Terminal Connections	2-30
2.6.3 Remote Control Terminal Connections	2-33
2.7 FACTORY DEFAULT SETTINGS	2-36

CHAPTER 3 OPERATION

3.1 GENERAL	3-1
3.1.1 Start-Up	3-1
3.1.2 Local Operation	3-1
3.1.3 Emergency Operation	3-1
3.1.4 Power-Down	3-1
3.2 ST-8000 FRONT PANEL	3-3
3.3 KEYPAD ENTRY	

ST-8000A OPERATOR'S MANUAL

3-5	3.3.1	Number Keys
3-5	3.3.2	ENTER Key
3-5	3.3.3	M/S CENT Key
3-5	3.3.4	BIT Key
3-6	3.3.4.1	Internal BIT
3-6	3.3.4.2	Internal Options
3-7	3.3.5	2ND Key
3-7	3.3.6	FSK Key
3-8	3.3.7	MARK ONLY Key
3-8	3.3.7.1	MARK (first level)
3-8	3.3.7.2	MARK ONLY (2nd level)
3-9	3.3.8	SPACE ONLY Key
3-9	3.3.8.1	SPACE (first level)
3-9	3.3.8.2	SPACE ONLY (2nd level)
3-10	3.3.9	DIV Key
3-10	3.3.10	MUTE Key
3-10	3.3.11	REMOTE Key
3-11	3.3.12	AMH HOLD Key
3-11	3.3.12.1	AMH (first level)
3-11	3.3.12.2	HOLD (2nd level)
3-11	3.3.13	NOR REV Key
3-12		

ST-8000A OPERATOR'S MANUAL

3-12	3.3.13.1 NORM (first level)
3-12	3.3.13.2 REV (2nd level)
3-12	3.3.14 SYNCH REGEN Key
3-12	3.3.14.1 SYNCH (first level)
3-12	3.3.14.2 REGEN (2nd level)
3-13	3.3.15 CHAN Key
3-13	3.3.15.1 CHAN (first level)
3-14	3.3.15.2 CHAN (2nd level)
3-14	3.3.16 BAUD RATE Key
3-14	3.3.17 CLEAR Key
3-14	TABLE OF CONTENTS (Continued) :
3-15	3.4 NUMERICAL DISPLAYS
3-15	3.5 MODE INDICATORS
3-15	3.6 BAR INDICATORS
3-17	3.7 MODULATOR OUTPUT LEVEL
3-17	3.8 OPERATIONAL MODES
3-17	3.8.1 Start-Up
3-17	3.8.2 Local Operation
3-18	3.8.3 Standby Mode
3-19	3.8.4 Emergency Operation
3-19	

CHAPTER 4 REMOTE CONTROL

ST-8000A OPERATOR'S MANUAL

4.1	ST-8000A REMOTE CONTROL SET-UP
4-1	4.1.1 Remote Control Data Rate
4-1	4.1.2 Unit Addressing
4-1	4.2 REMOTE CONTROL PROTOCOL
4-2	4.3 CONTROL COMMANDS
4-3	4.4 STATUS RESPONSES
4-5	4.4.1 Long Format
4-5	4.4.2 Long Format Examples
4-6	4.4.3 Short Format
4-7	4.4.4 Short Format Examples
4-7	4.4.5 Other Status Responses
4-8	4.4.6 HELP Page 1
4-10	4.4.7 HELP Page 2
4-11	4.4.8 HELP Page 3
4-12	4.5 INTERNAL BIT
4-13	4.6 ERROR MESSAGES
4-15	4.7 OPERATING PROCEDURES
4-16	4.7.1 Local Operation
4-16	4.7.1.1 Standby Operation
4-16	4.7.1.2 Shut-Down
4-16	4.7.2 Remote Operation
4-16	4.7.2.1 Start-Up

ST-8000A OPERATOR'S MANUAL

4-16	4.7.2.2 Standby Operation
4-16	

CHAPTER 5 THEORY OF OPERATION

5.1	GENERAL
5-1	
5.2	FSK SYSTEM APPLICATION
5-1	
5-1	5.2.1 Radio FSK Data System
5-2	
5-2	5.2.2 Wire Line FSK Data System
5-2	
5.3	FUNCTIONAL DESCRIPTION
5-2	
5-4	5.3.1 Demodulator Circuits
5-7	
5-7	5.3.2 Modulator and Keyline Circuits
5-9	
5-9	5.3.3 Digital Control Circuitry
5-11	
5-11	5.3.4 Front Panel
5-13	
5-13	5.3.5 Power Supply
5-13	
5-13	5.3.6 Cabinet

ST-8000A OPERATOR'S MANUAL

TABLE OF CONTENTS (Continued) :

CHAPTER 6 MAINTENANCE

6.1	GENERAL
6-1	
6.2	DEPOT MAINTENANCE
6-1	
6.3	ROUTINE MAINTENANCE
6-2	
6.4	POWER-ON SYSTEM TEST (POST)
6-2	
6.5	BUILT-IN-TESTS (BIT)
6-3	
6.5.1	Purpose
6-3	
6.5.2	BIT Activation
6-3	
6.5.2.1	BIT Entry via Front Panel Keypad
6-4	
6.5.2.2	BIT Entry via Remote Control Commands
6-4	
6.5.3	BIT Test Result Indications
6-5	
6.5.3.1	BIT Step Successful
6-5	
6.5.3.2	BIT Step Failure
6-5	
6.5.4	ST-8000A BIT Steps
6-7	
6.5.4.1	Microprocessor Alive test (Test 0) ..
6-7	
6.5.4.2	Internal Clock Test (Test 1)
6-7	
6.5.4.3	ROM Checksum Test (Test 2)
6-7	
6.5.4.4	Random Access Memory Test (Test 3) ..
6-8	
6.5.4.5	EEPROM Test (Test 4)
6-8	
6.5.4.6	Front Panel Indicator Test (Test 5) ..
6-8	

ST-8000A OPERATOR'S MANUAL

6-9	6.5.4.7 Loopback Data Test #1 (Test 6)
6-9	6.5.4.8 Loopback Data Test #2 (Test 7)
6-10	6.5.4.9 Loopback Data Test #3 (Test 8)
6-10	6.5.4.10 Loopback Data Test #4 (Test 9)
6-11	6.5.4.11 Loopback Data Test #5 (Test A)
6-11	6.5.4.12 Remote Port Test (Test B)
6-12	6.5.4.13 Deadman Timer Test (Test C)
6-12	6.5.4.14 Final BIT Report
6-12	6.5.4.15 Restore Parameters
6-13	6.5.5 BIT Execution Times
6-14	6.5.6 Manual Test Selection
6-14	6.6 ADDITIONAL FAULT IDENTIFICATION
6-15	6.7 RETURN TO FACTORY

APPENDICIES

A-1	APPENDIX A, FCC PART 15 VERIFICATION
B-1	APPENDIX B, WARRANTY

ST-8000A OPERATOR'S MANUAL

TABLES:

TABLE 2.1	ST-8000 ACCESSORIES
2-3	
TABLE 2.2	INTERNAL OPTION LOG
2-20	
TABLE 2.3	AUDIO I/O CONNECTOR J2
2-21	
TABLE 2.4	DATA I/O CONNECTOR J1
2-30	
TABLE 2.5	REMOTE CONTROL CONNECTOR J4
2-33	
TABLE 3.1	BIT ROUTINES
3-6	
TABLE 3.2	DISPLAY OF INTERNAL OPTIONS
3-7	
TABLE 4.1	REMOTE CONTROL DATA RATE SET-UP
4-1	
TABLE 4.2	REMOTE CONTROL ADDRESS SET-UP
4-2	
TABLE 4.3	ST-8000A REMOTE CONTROL COMMANDS
4-3	
TABLE 4.4	LONG COMMAND FORMAT
4-5	
TABLE 4.5	SHORT COMMAND FORMAT
4-7	
TABLE 4.6	G COMMAND RESPONSES
4-8	
TABLE 4.7	HELP PAGE 1
4-10	
TABLE 4.8	HELP PAGE 2
4-11	
TABLE 4.9	HELP PAGE 3
4-12	
TABLE 4.10	BIT T1 RESPONSE
4-13	
TABLE 4.11	REMOTE COMMAND ERROR RESPONSES
4-15	
TABLE 6.1	BIT STEP EXECUTION TIMES
6-13	

ST-8000A OPERATOR'S MANUAL

FIGURES:

FIGURE 1.1	ST-8000A MODEM
viii		
FIGURE 2.1	ST-8000A PACKAGING FOR SHIPMENT
2-2		
FIGURE 2.2	ST-8000A REAR PANEL
2-5		
FIGURE 2.3	MILITARY AC POWER ADAPTER CABLE
2-7		
FIGURE 2.4	USER-SET OPTION SWITCHES AND JUMPERS
2-10		
FIGURE 2.5	DEMODULATOR INPUT IMPEDANCE (A1J6)
2-11		
FIGURE 2.6	AMH THRESHOLD AND DELAY (A1SW1, A1SW2)
2-12		
FIGURE 2.7	LOS/CD JUMPER (A1J9)
2-13		
FIGURE 2.8	AUTO-MUTE JUMPER (A1J8)
2-13		
FIGURE 2.9	REMOTE CONTROL DATA RATE (A2SW3)
2-14		
FIGURE 2.10	REMOTE CONTROL ADDRESS (A2SW4)
2-15		
FIGURE 2.11	AUTO-MUTE DELAY (A2SW1, A2SW2)
2-17		
FIGURE 2.12	RS-232 / MIL-188 JUMPERS (A2J2, A2J6, A2J7)	...
2-18		
FIGURE 2.13	REMOTE CONTROL TERMINATIONS (A2J4 AND A2J8)
2-19		
FIGURE 2.14	TYPICAL RADIO DATA SYSTEM
2-23		
FIGURE 2.15	RADIO SYSTEM CONNECTIONS
2-24		
FIGURE 2.16	TYPICAL FDX WIRE-LINE SYSTEM
2-26		
FIGURE 2.17	4-WIRE LINE CONNECTIONS
2-27		
FIGURE 2.18	2-WIRE LINE CONNECTIONS
2-29		
FIGURE 2.19	DATA I/O CONNECTIONS

ST-8000A OPERATOR'S MANUAL

2-32	
FIGURE 2.20	REMOTE CONTROL CONNECTIONS
2-34	
FIGURE 2.21	ALTERNATE REMOTE CONTROL CONNECTIONS
2-35	
FIGURE 2.22	MULTI-UNIT REMOTE CONTROL CONNECTION
2-37	

ST-8000A OPERATOR'S MANUAL

FIGURES (Continued) :

FIGURE 3.1	ST-8000A FRONT PANEL
3-2	
FIGURE 3.2	ST-8000A FRONT PANEL KEYPAD
3-4	
FIGURE 3.3	ST-8000A FRONT PANEL DISPLAYS
3-16	
FIGURE 5.1	ST-8000A INTERNAL ASSEMBLIES
5-3	
FIGURE 5.2	DEMODULATOR CIRCUIT
5-6	
FIGURE 5.3	MODULATOR CIRCUIT
5-8	
FIGURE 5.4	MICROPROCESSOR CONTROL
5-10	
FIGURE 5.5	FRONT PANEL
5-12	

ST-8000A OPERATOR'S MANUAL

THIS PAGE LEFT BLANK INTENTIONALLY

ST-8000A OPERATOR'S MANUAL

FIGURE 1.1 ST-8000A MODEM
viii

HAL910416
870-08005