

CHAPTER 5 ALIGNMENT AND TEST

CONTENTS:

5.1 GENERAL 5-1

5.1.1 Internal Access 5-1

5.1.2 Removing Top Cover 5-1

5.1.3 Control Board Service Position 5-2

5.2 ST8000A ALIGNMENT 5-5

5.2.1 Alignment Tools and Instruments 5-5

5.2.2 Preliminary Test 5-7

5.2.3 Confirm DC Power Supply Voltages 5-7

5.2.3.1 POWER SUPPLY (A4) Voltages 5-7

5.2.3.2 MODEM (A1) Voltages 5-8

5.2.3.3 CONTROL (A2) Voltages 5-8

5.2.3.4 FRONT PANEL (A3) Voltages 5-9

5.2.4 BIT Calibration 5-10

5.2.5 MARK Filter Alignment 5-11

5.2.6 SPACE Filter Alignment 5-11

5.2.7 Bar Graph Alignment 5-12

5.2.8 AMH and Gain Control Alignment 5-13

5.2.9 MARK and SPACE Offset Adjustment 5-14

5.2.10 High Speed Demodulator Filter Alignment 5-14

5.2.11 High Speed Detector Alignment 5-16

5.2.12 Restore to Operation 5-17

5.3 ST8000A TEST PROCEDURES 5-19

5.4 BUILT-IN-TEST (BIT) 5-

FIGURES:

Figure 5.1 CONTROL BOARD IN SERVICE POSITION 5-4

Figure 5.2 MODEM BOARD TEST POINTS AND CONTROLS 5-6